

Windows Standard VPN Client 6.87

Administrator's Guide

Latest update: 17 June 2022
Document reference number: 20220617_AG_VPN_6.8_EN_1.2

Table of contents

1	Overview.....	4
1.1	Introduction	4
1.2	Important information	4
1.3	What's new in release 6.8	5
2	Installing the software	6
2.1	Introduction	6
2.2	Installation procedure	7
2.3	Canceling installation	13
2.4	Trial period	13
2.5	Configuring Windows	15
3	Activating the software.....	16
3.1	Step 1.....	16
3.2	Step 2.....	16
3.3	Activation errors	17
3.4	Manual activation	18
3.5	Temporary license.....	20
3.6	License and activated software.....	22
4	Updating the software.....	23
4.1	How to get an update	23
4.2	Update procedure	24
4.3	Updating the VPN configuration.....	24
5	Uninstalling the software.....	25
6	Getting started with the software	26
6.1	Introduction	26
6.2	Starting the software	26
6.3	Opening a test VPN tunnel from the Connection Panel	28
6.4	Configuring a VPN tunnel.....	31
6.5	Automating the opening of a VPN tunnel	31
7	Configuration wizard	32
7.1	Step 1.....	33
7.2	Step 2.....	33
7.3	Step 3.....	35
8	Connection Panel	36
9	Configuration Panel	37
9.1	Menus	38
9.2	Status bar.....	38
9.3	Shortcuts	38
9.4	VPN configuration tree	39
10	"About..." window	43
11	Importing and exporting the VPN configuration	44
11.1	Importing a VPN configuration	44
11.2	Exporting a VPN configuration	46
11.3	Merging VPN configurations	46
11.4	Splitting a VPN configuration	46
12	Configuring a VPN tunnel	47
12.1	IPsec IKEv1, IPsec IKEv2 or SSL VPN.....	47
12.2	Editing and saving a VPN configuration.....	47
12.3	Configuring an IPsec IKEv1 tunnel.....	48
12.4	Configuring an IPsec IKEv2 tunnel.....	60

12.5	Configuring an SSL VPN tunnel.....	69
13	Redundant gateway.....	77
14	Automation.....	78
15	Fallback tunnel.....	80
16	IPv4 and IPv6.....	81
17	Managing certificates.....	82
17.1	Selecting a certificate ("Certificate" tab).....	82
17.2	Selecting the certificate automatically.....	84
17.3	Importing a certificate.....	84
17.4	Windows Certificate Store.....	86
17.5	VPN gateway certificate.....	86
17.6	Managing certificate authorities.....	86
17.7	Using a certificate stored on a smart card or token.....	87
18	Remote Desktop Sharing.....	89
19	Managing the Connection Panel.....	90
20	USB mode.....	92
20.1	Overview.....	92
20.2	Configuring the USB mode.....	92
20.3	Using the USB mode.....	95
21	GINA mode.....	97
21.1	Overview.....	97
21.2	Configuring the GINA mode.....	97
21.3	Using the GINA mode.....	97
22	Options.....	99
22.1	Displaying/hiding the interface.....	99
22.2	General.....	100
22.3	Managing logs.....	101
22.4	PKI options.....	101
22.5	Managing languages.....	102
23	Administrator logs, console and traces.....	104
23.1	Administrator logs.....	104
23.2	Console.....	105
23.3	Trace mode.....	106
24	Security recommendations.....	107
24.1	Assumptions.....	107
24.2	User workstation.....	107
24.3	VPN Client administration.....	107
24.4	VPN configuration.....	108
25	Appendixes.....	110
25.1	Shortcuts.....	110
25.2	Administrator logs.....	111
25.3	Technical data of the Windows Standard VPN Client.....	112
25.4	Third-party licenses.....	114
26	Contact.....	118
26.1	Information.....	118
26.2	Sales.....	118
26.3	Support.....	118

1 Overview

1.1 Introduction

Thank you for downloading our Windows Standard VPN Client software.

The Standard edition is made for private individuals and SMBs. It provides a high level of communication security and is also easy to deploy, integrate, and use.

As it does not require the existing infrastructure to be reconsidered (OS, network, PKI), the Windows Standard VPN Client is designed to be transparently integrated into the security policies that have been set up.

The Windows Standard VPN Client is marketed on the basis of a perpetual license. You can also subscribe to an annual subscription to benefit from dedicated support and ongoing software maintenance.

1.2 Important information

1.2.1 Encrypted configuration files

VPN configuration files from versions of the Windows Standard VPN Client prior to 6.8 cannot be imported into the Configuration Panel.

During a software update, the installer will convert the existing configuration before it automatically imports the file into the Configuration Panel.

1.2.2 Check Gateway Certificate

By default, the gateway certificate will be checked each time a tunnel is opened. It may be necessary to import the complete chain of certificate authorities (CA) to authenticate the gateway, either into the Windows store or into the VPN configuration file.

You can change this default behavior, though we do not recommend doing so (Options menu -> PKI Options).

1.2.3 End of support for “weak” algorithms

For security reasons, this version no longer supports the following algorithms: DES, 3DES, MD-5, SHA-1, DH 1-2, DH 5. If a previous configuration contains one of these algorithms, the installer will convert them to “auto” (automatic negotiation with the gateway).

If the gateway only supports this type of algorithm, you will not be able to establish a connection with this version of the VPN client.

1.3 What's new in release 6.8

1.3.1 Installation and configuration

- Use of a Microsoft Windows Installer (MSI) to facilitate deployment and software updates
- The following items will be preserved when updating from version 6.64:
 - Software settings
 - VPN configuration
 - License
- The entire software is compiled in 64-bit mode for Windows 10 & 11 for optimized performance and security
- Access to the VPN configuration can be restricted to Windows administrators

1.3.2 Cryptography

- Support for RFC 4304 Extended Sequence Numbers (ESNs) and RFC 6023 (Childless IKE Initiation) for enhanced security
- Support for the following digital signature authentication algorithms for strong certificate authentication:
 - Method 9: ECDSA “secp256r1” with SHA-256 on the P-256 curve [RFC 4754]
 - Method 10: ECDSA “secp384r1” with SHA-384 on the P-384 curve [RFC 4754]
 - Method 11: ECDSA “secp521r1” with SHA-512 on the P-521 curve [RFC 4754]
 - Method 14: Digital Signature Authentication PKCS1-v1.5 [RFC 7427]
- The following algorithms, which are known to be vulnerable, are no longer supported in version 6.8 and higher: DES, 3DES, SHA, DH 1-2, DH 5
- Reinforced encryption and integrity of the VPN configuration

1.3.3 Smart cards and tokens

- Support for the Microsoft CNG API (Cryptography API: Next Generation) allows for the latest generation of smart cards and tokens to be used
- Microsoft has deprecated the Cryptographic Service Providers (CSP) API, it is no longer supported for IKEv2 as of version 6.8

1.3.4 Protecting VPN configurations

- Option for restricting the VPN configuration to OS administrators only
- Password has been removed from Configuration Panel
- Increased configuration file protection with SHA-2

1.3.5 SSL/TLS

- Support for Lz4 compression

2 Installing the software

2.1 Introduction

The Windows Standard VPN Client is installed by executing the program that you can download from [TheGreenBow's website](#).

The default installation procedure, which consists in double-clicking the icon of the program you have downloaded, opens a window that allows you to customize the installation.



Refer to section 2.2 Installation procedure.

2.1.1 Installation conditions

The Windows Standard VPN Client is available for the 64-bit version of Windows 10 & 11.

The minimum system requirements to install the software are as follows:


- Processor: 1 gigahertz (GHz) or faster processor
- RAM: 2 GB
- Hard disk space available: 40 MB

When the software is not installed from an administrator account, a window opens, prompting you for the username and password of an administrator account on the machine.

2.1.2 Digital signature and version

The installer software for the Windows Enterprise VPN Client is signed with a certificate issued for "THEGREENBOW SA". This allows the person performing the installation or the user to verify the integrity of the installation program at any time.

You can verify the authenticity of the software by displaying the program's properties (right-click MSI installer) and then selecting the "Digital signatures" tab.



Users can check the version number of the Windows Standard VPN Client in the “About...” window of the software.

☞ Refer to chapter 10 “About...” window.

2.1.3 Vulnerabilities

Moreover, users of the Windows Standard VPN Client who send an e-mail with their contact details to referent@thegreenbow.com will be warned of any vulnerabilities identified in the software and receive information on the means to remedy them (new version, update, available patches, workarounds, etc.).

2.2 Installation procedure



See also our [security recommendations](#).

Once you have downloaded the Windows Standard VPN Client installer and verified its authenticity (see section 2.1.2 Digital signature and version above), you can proceed with its installation by following the steps described below.




You can only update the software if you install a minor update or if you subscribed to ongoing maintenance (see section 4.1 How to get an update).

The installation procedure is the same whether it is an initial installation or an update (see chapter 4 Updating the software). When performing an update, the software settings, the existing VPN configuration, and the license are preserved.




When installing and using the software, administrators must have read and write access to the folder "C:\ProgramData\".


- 1/ Double-click the installation program you downloaded. The following window is displayed:



- 2/ Click "Next". The following window is displayed:



- 3/ Read the End User License Agreement (EULA) carefully. If you accept all the terms of the agreement, select the "I accept the terms of the license agreement" checkbox, and then click "Next". Otherwise, you will not be able to continue installing the Windows Standard VPN Client. The following window is displayed:




- 4/ Carefully read the information about what's new and the note about how the existing VPN configuration will be converted during an update.




Once the installation is complete, you will not be able to revert to an earlier version of the software without manual intervention. If in doubt, back up your VPN configuration to a separate folder or to a removable storage medium.


If you accept all the terms of the agreement, select the "I accept the new changes" checkbox, and then click "Next". The following window is displayed:



- 5/ If you want to install the Windows Standard VPN Client in a specific directory, click “Change...” and select the desired directory. Otherwise, you can keep the default directory. Then, click « Next ». The following window is displayed:




- 6/ The program is ready to install. If you want to go back to check or change your installation settings, click “Back”. Otherwise, click “Install”. If you are installing from an account that does not have administrator rights, the following window is displayed:




- 7/ To proceed with the installation, you must enter an administrator name and password to allow the installation program to make changes to your computer. Otherwise, the software will not be installed.

If you are installing from an administrator account, you do not need to enter a password. Simply confirm that you allow the app to make changes to your device.

8/ Installation begins and the following window is displayed:




9/ Wait for the installation of the Windows Standard VPN Client including all its components to complete. If installation has succeeded, the following window is displayed:



10/ If you do not want to launch the VPN Client immediately, uncheck the corresponding box. To exit the setup wizard, click "Finish".

If you have performed an update, the software is launched directly in the taskbar. You can test your installation by opening the test tunnel (see section 6.3 Opening a test VPN tunnel from the Connection Panel).

Otherwise, the activation screen is displayed:



11/ The Windows Standard VPN Client is now installed on your workstation.

If you already own a license for the Windows Standard VPN Client:

- Select "I want to Activate the software"
- Enter the license number and activation e-mail
- Then, click "Next"

For further details on the activation procedure, refer to chapter 3 Activating the software.

If you want to try the Windows Standard VPN Client:

- Select "I want to Evaluate the software"
- Then, click "Next"

You will then be able to use the software for a 30-day trial period. For further details on the trial period, refer to section 2.4 Trial period.


If you do not have a license and want to buy one, click "Buy a license". TheGreenBow online store is displayed in a browser window. Here, you can buy one or several licenses. For further details on the activation procedure, refer to chapter 3 Activating the software.

You are now ready to use the software. You can continue with the following steps:

- To start using the Windows Standard VPN Client immediately, refer to chapter 6 Getting started with the software.
- To use the configuration wizard to quickly create a VPN connection, refer to chapter 7 Configuration wizard.
- To import a TheGreenBow VPN configuration compatible with this version of the software, refer to section 11.1 Importing a VPN configuration.
- For a detailed presentation of the available interfaces, refer to chapters 8 Connection Panel and 9 Configuration Panel.
- For a comprehensive explanation of all tunnel configuration options, refer to chapter 12 Configuring a VPN tunnel.
- To uninstall the Windows Standard VPN Client, refer to chapter 5 Uninstalling the software.

2.3 Canceling installation

If you cancel the setup wizard before clicking the “Install” button, the following window is displayed:




Your system has not been modified and you can resume installation at a later time.

2.4 Trial period


The first time the software is installed on a workstation, if no license key is provided to the installer, the VPN Client will enter into a 30-day trial period. During this trial period, the VPN Client is fully operational and all functions are unlocked.

The activation window will be displayed every time the software is started during the trial period. It shows the number of days remaining in the trial period.




Select “I want to Evaluate the software”, then click “Next >” to run the software.

During the trial period, the “About...” window will display the number of days remaining until the trial ends.




During the trial period, the activation window can be accessed at any time through the "? > Activation wizard" menu of the main interface (Configuration Panel).



2.5 Configuring Windows

Once you have completed installation, make sure the Windows privacy option “Use my sign-in info to automatically finish setting up my device after an update or restart”, found under the “Sign-in options” in the Windows Settings, is disabled, as shown in the screenshot of the Windows 10 Settings below:



The same option is available in the Windows 11 Settings.

3 Activating the software

The VPN Client must be activated to continue to work beyond the trial period.

The activation procedure can be accessed every time the software is launched or from the “? > Activation Wizard...” menu in the main interface.


3.1 Step 1

If you do not yet have a license, click on “Buy a license”. TheGreenBow online store is displayed in a browser window. Follow the instructions to buy one or several licenses.

In the “License number” field, enter the license number you received by e-mail. The license number can be copy-pasted directly from the purchase confirmation e-mail into this field.

The license number consists of the characters [0..9] and [A..F], possibly grouped 6 by 6 and separated by hyphens.

In the “Activation email” field, enter the e-mail address used to identify your activation. This information is used for recovering the activation information if it is lost.



The screenshot shows a dialog box titled "TheGreenBow VPN Client" with a green header bar that says "Software Activation". Below the header, it says "Welcome". There are two radio buttons: "I want to Activate the software" (selected) and "I want to Evaluate the software". Under "I want to Activate the software", there is a "License number:" field containing "123456-123456-123456-123456" and an "Activation email:" field containing "jane.doe@domain.com". Below these fields is a link "I don't have a license: Buy a license" with a shopping cart icon. On the right side, under "I want to Evaluate the software", there is a green progress bar and the text "30 days left" and "In 30 days, you will be unable to use your software until you complete the activation process." At the bottom, there are "Quit" and "Next >" buttons.



The “Activation email” field is filled by default with the username of the workstation on which the software is installed (as follows: “username@company.com”). This allows administrators of a “master” software license to individually identify all activated workstations. It allows them to manage software activations and deactivations in a deterministic way.

3.2 Step 2

Click “Next >”. The online activation process will run automatically.


Once the activation has been carried out successfully, click “Run” to run the software.



The software activation is linked to the workstation on which the software has been installed. Consequently, a license number allowing a single activation cannot be reused on another workstation once it is activated. Conversely, a license number activation can be canceled by simply uninstalling the software.

3.3 Activation errors

Software Activation may fail for various reasons. The error is always displayed in the activation window. It is sometimes followed by a link that displays more information about the error or suggests actions to solve the problem.




TheGreenBow lists all activation errors and [procedures for solving activation issues](#) on its website.

The following are the most common activation errors:

#	Meaning	Troubleshooting
31	Wrong license number	Check license number
33	The license number is already activated on a different workstation	Uninstall the software on the workstation with the activated license or contact TheGreenBow's Sales department
53, 54	Communication with the activation server is impossible	Ensure that the workstation is connected to the internet. Check that communication is not blocked by a firewall or proxy. Configure the firewall to let the communication through or the proxy to reroute it properly.

3.4 Manual activation

When activation fails because of a communication issue with the activation server, the software can be activated manually on [TheGreenBow's website](#). The procedure is as follows:



- ① `product.dat` file Retrieve the `product.dat` file from the “My Documents” directory in Windows on the workstation that you want to activate. (1)
- ② Activate On a workstation that is connected to the activation server (2), open the manual activation page (3), and post the `product.dat` file. Let the server automatically create the `tgbcode` before downloading it.
- ③ `tgbcode` file Copy the `tgbcode` file to the “My Documents” directory in Windows on the workstation that you want to activate. Start the software; it will be activated.


(1) The `product.dat` file is a text file that contains the workstation information used for the activation. If this file cannot be found in the “My Documents” directory, carry out the software activation steps on the workstation. This will generate the file even if activation fails.

(2) The activation server is the TheGreenBow server, which can be accessed on the internet.

(3) Refer to the detailed procedure below.

To proceed with manual activation, follow the steps below:

- 1/ On a workstation connected to TheGreenBow's website, open the following webpage:
<https://www.thegreenbow.com/en/support/license-management/manual-license-activation/>



Manual license activation

This page enables to Offline Activate TheGreenBow Software whenever you experience online activation problems (such as activation server unreachable, problem of internet connexion, etc..).

Step 1 – Sending the product.dat file

To proceed to a Manual Software Activation, you will need the activation file 'product.dat'.

i Where can I find the activation file 'product.dat' on my computer ?


Attachment [Add a file](#)

The files must be in .DAT format and must be less than 5MB in size.

Step 2 – Analysis

Step 3 – Activation

- 2/ Click “Add a file” and open the `product.dat` file created on the workstation that you want to activate.
- 3/ Click “Submit”. The activation server will check the validity of the information contained in the `product.dat` file.
- 4/ Click “Proceed”. The activation server will provide a link to download a file containing the activation code for the workstation to be activated.



Manual license activation

This page enables to Offline Activate TheGreenBow Software whenever you experience online activation problems (such as activation server unreachable, problem of internet connexion, etc..).

Step 1 – Sending the product.dat file

Step 2 – Analysis

Step 3 – Activation

✓ Your activation code is correctly generated.

To activate your software :

- Download your activation file below
- Copy it to the directory where you found "product.dat"
- Quit and restart your software

[Download the .dat file](#)

The file name has the following format: `tgbcode_[date]_[code].dat` (e.g. `tgbcode__20210615_1029.dat`).

3.5 Temporary license

You can request TheGreenBow trial licenses, called temporary licenses, for example to continue using the software beyond the end of the standard trial period.

If you would like to get a temporary license, please contact the Sales department by e-mail at sales@thegreenbow.com

To activate the temporary license, enter the license number and activation e-mail in the corresponding fields:

TheGreenBow VPN Client

Software Activation

Welcome

I want to Activate the software I want to Evaluate the software

License number:
123456-123456-123456-123456

Activation email:
jane.doe@domain.com

I don't have a license:
 Buy a license

Quit Next >

30 days left
In 30 days, you will be unable to use your software until you complete the activation process.

Then, click « Next ». A confirmation window is displayed:

TheGreenBow VPN Client


Software Activation

Activation completed.

Software activation successful (Temporary License).
You have now 6 days to evaluate the software.


Run

The activation window will continue to appear when the software starts for as long as a temporary license is used. A calendar icon indicates that this license is temporary, and the number of days remaining is shown.



Click "Next >" to run the software.


You will find all the information about the license number and e-mail address used for activation in the "About..." window (see chapter 10 "About..." window):



Once the validity period of the temporary license expires, you must activate the software with a definitive license in order to keep using it.


3.6 License and activated software

Once the software is activated, the license number and e-mail address used for activation can be viewed in the “About...” window of the software (see chapter 10 “About...” window).




4 Updating the software

You can also check whether an update is available for the software at any time using the main interface menu “? > Check for update”.



This menu opens the web page used to check for updates. This page will display whether an update is available and can be activated, according to the type of license you have purchased and to the type of maintenance or subscription you have chosen. To get this information, you must enter the license number in the corresponding field on the verification page, which can also be viewed directly under the following link: <https://www.thegreenbow.com/en/support/license-management/checking-license/>.

Example:



4.1 How to get an update

Software updates are provided according to the following rules:

During the maintenance period (1)	All updates can be installed
Outside the maintenance period or without a maintenance agreement	All minor updates can be installed (2)

(1) The maintenance period starts on the date of purchase of the software.

(2) Minor updates (or maintenance updates) are identified by the last digit of the version number, e.g. the last “6” in “6.86”.

Performing an update from an Enterprise, Premium, or Certified edition to a Standard edition and vice versa is not allowed.



Example:

You activated version 6.86 of the software. Your maintenance period has expired.


All updates from versions 6.87 to 6.89 are authorized.

All updates from version 6.90 and higher will be denied.

4.2 Update procedure

Updating the Windows Standard VPN Client allows you to upgrade to a newer version of the software while preserving the settings, the VPN configuration, and the license. It is performed in the same way as a normal installation (see section 2.2 Installation procedure) except in the following two cases:

- 1/ If the license of the installed product is not compatible with the Windows Standard VPN Client 6.8, it will not be possible to update the software.
In this case, you will need to uninstall the previous version of the software before you install the new one.
- 2/ If access to the Configuration Panel is protected by a password on the version that is already installed, the update cannot be performed using the graphical interface of the installation program. In this case, the following screen is displayed:



We recommend removing the password protection for access to the Configuration Panel in the installed version. The update can then be performed normally.



Password protection for access to the Configuration Panel has been replaced in version 6.8 of the Windows Standard VPN Client by a more secure mechanism. It consists in limiting access to the Configuration Panel to Windows administrators only. This option is not enabled by default but can be enabled as described in section 22.1 Displaying/hiding the interface, check the “Restrict access to Configuration Panel to administrator” option.

4.3 Updating the VPN configuration

The VPN configuration is automatically backed up and restored during an update.




If access to the Configuration Panel is password-protected, you must enter the password during the update to authorize configuration restoration.

5 Uninstalling the software


To uninstall the VPN Client, proceed as follows:

- 1/ Open the Windows Control Panel.
- 2/ Select « Uninstall a program ».
- 3/ Select “TheGreenBow VPN Client” in the list of programs.
- 4/ Click “Uninstall” and follow the instructions to uninstall the program.



OR

- 1/ Open the Windows “Start” menu.
- 2/ Right-click the “TheGreenBow VPN Client” program, then select “Uninstall”.



- 3/ The Windows Control Panel is displayed. Select “TheGreenBow VPN Client” in the list of programs.
- 4/ Click “Uninstall” and follow the instructions to uninstall the program.



Administrator privileges are required to install or uninstall the program on the workstation.

6 Getting started with the software

6.1 Introduction

The Windows Standard VPN Client graphical interface allows you to perform the following actions:

- 1/ Configure the software (startup mode, language, access control, etc.)
- 2/ Manage VPN tunnel configurations, certificates, imports, exports, etc.
- 3/ Use VPN tunnels (open, close, identify incidents, etc.)

The graphical interface includes the following elements:

- The [Connection Panel](#) (list of VPN tunnels to open)
- The [Configuration Panel](#), which can be displayed from the Connection Panel or using the icon in the taskbar and consists of the following items:
 - o A [set of menus](#) for VPN configuration and software management
 - o The [VPN configuration tree](#)
 - o VPN tunnel configuration tabs
 - o A [status bar](#)
- An [icon on the taskbar](#) and the associated menu

6.2 Starting the software


Once the installation or update is complete, if you have not unchecked the “Launch VPN Client” box and you have not activated the software, the activation window is displayed (see chapter 3 Activating the software). When the software has been activated or if you choose to try it out, the Windows Standard VPN Client will start minimized and the TheGreenBow VPN Client icon will appear in the taskbar. The taskbar icon is described in detail in the paragraph entitled [Taskbar icon](#) below.

If you have unchecked the “Launch VPN Client” checkbox at the end of the installation or update procedure, or if you want to use the test tunnel after having installed or updated the software, to start the Windows Standard VPN Client, you can either double-click the corresponding desktop icon or open the Windows “Start” menu and then select the program in the list.

Starting the VPN Client using the shortcut on the desktop

During the installation of the software, a shortcut to run the application is created on the Windows desktop.


The Windows Standard VPN Client can be started directly by double-clicking this icon.



The VPN Client will start minimized and the TheGreenBow VPN Client icon will appear in the taskbar (see paragraph entitled [Taskbar icon](#) below).

Starting the VPN Client using the Windows Start menu

Once the installation is complete, you can start the Windows Standard VPN Client by clicking on the TheGreenBow VPN Client program name in the Windows "Start" menu.




The VPN Client will start minimized and the TheGreenBow VPN Client icon will appear in the taskbar (see paragraph entitled [Taskbar icon](#) below).

Running the VPN Client as administrator


Access to the VPN Client's Configuration Panel may be restricted to Windows administrators only (see section 22.1 Displaying/hiding the interface).

If the "Restrict access to Configuration Panel to administrator" option is enabled, to start the VPN Client in administrator mode and be able to access the Configuration Panel, right-click the TheGreenBow VPN Client icon and then select "Run as administrator".



Taskbar icon

Under normal operating conditions, the taskbar icon shows the status of the Windows Standard VPN Client Connection Panel/Configuration Panel.



The color of the icon changes when a VPN tunnel is open:



Blue icon: no VPN tunnel open




Green icon: at least one VPN tunnel is open

The tooltip for the icon always shows the software status:

- "VPN Tunnel opened" if one or several tunnels are open
- "TheGreenBow VPN Client" when the VPN Client is running, but no tunnels are open

Left-clicking the icon opens the Connection Panel.

Right-clicking the VPN Client icon in the taskbar opens the contextual menu associated with the icon:



The administrator can limit the options displayed in the menu (see section 22.1 Displaying/hiding the interface). The contextual menu contains the following items:

- 1/ Connection Panel: opens the Connection Panel
- 2/ Configuration Panel: opens the Configuration Panel
- 3/ Console: opens the VPN traces window
- 4/ Quit: closes all open VPN tunnels and quits the software




When the “Restrict access to Configuration Panel to administrator” option is enabled and the user selects the “Configuration Panel” option, a message is displayed indicating that the software must be run as administrator to access the Configuration Panel (see paragraph [Running the VPN Client as administrator](#) above).


6.3 Opening a test VPN tunnel from the Connection Panel

The Windows Standard VPN Client comes equipped with a VPN configuration containing a VPN test tunnel named “TgbTest-TgbTest”.

To open the Connection Panel, right-click the taskbar icon (see the paragraph entitled [Taskbar icon](#) above), and then select the “Connection Panel” menu item. The Connection Panel is described in chapter 8 Connection Panel.



In the Connection Panel, click the "OPEN" button next to the "TgbTest-TgbTest" tunnel.



When the "Restrict access to Configuration Panel to administrator" option is enabled and the software has not been run as administrator, the button with the three horizontal bars to the right of the question mark, which gives access to the Configuration Panel, is not displayed.

When opening or closing a VPN tunnel, a fade-out pop-up window appears above the VPN Client icon in the taskbar. This window shows the tunnel status when it is being opened or closed and automatically fades out unless the mouse cursor is placed directly over it:

Tunnel is being opened




Tunnel is open



Tunnel is closed



Failed to open the tunnel: the window will briefly explain what happened and provide a hyperlink for more information about the incident.



The fade-out window can be disabled. To do so, in the "Tools" menu select "Options", access the "View" tab and then check the "Don't show the systray sliding popup" option.

The tunnel opens and the following confirmation window is briefly displayed:



The TheGreenBow test website is then displayed in a browser window:


A screenshot of a web browser displaying the 'THEGREENBOW VPN TEST SERVER' page. The page has a dark blue header with the logo and title. The main content area features a green heading: 'Congratulations! You've successfully opened a VPN tunnel.' Below this, a paragraph explains that the machine's connectivity meets the requirements for IPsec VPN and that the webpage is on an extranet server. A diagram illustrates the connection: 'TheGreenBow VPN Client' (represented by a laptop and phone) connects via 'IPsec VPN' to a central 'Tunnel' (represented by a green shield icon). This tunnel connects to a 'VPN Gateway' (represented by a server icon) at 'tgbtest.dyndns.org', which is part of a 'Corporate Network' with IP address '192.168.175.0/24'. A grey footer section contains information about protocols that can be used with tunneling, including a NETBIOS link to a demo server: '\\192.168.175.50\share\'. It also mentions that RDP is possible but no login/password is provided for testing purposes only.



You can also open a test tunnel from the Configuration Panel (see chapter 9 Configuration Panel).


6.4 Configuring a VPN tunnel

To open the Configuration Panel, right-click the taskbar icon (see the paragraph entitled [Taskbar icon](#) above), and then select the “Configuration Panel” menu item. The Configuration Panel is described in chapter 9 Configuration Panel.



When the “Restrict access to Configuration Panel to administrator” option is enabled (see section 22.1 Displaying/hiding the interface), you must quit and restart the VPN Client as administrator to be able to access the Configuration Panel.

Then, open the configuration wizard by selecting the “Configuration > Wizard...” menu item.



Use the wizard as described in chapter 7 Configuration wizard below.



On our website, you will find many configuration guides for most VPN firewalls/routers/gateways: <https://www.thegreenbow.com/en/support/integration-guides/compatible-vpn-routers>.

6.5 Automating the opening of a VPN tunnel

The Windows Standard VPN Client allows you to automate the opening of a VPN tunnel. It can be opened automatically in the following ways:


- 1/ When Windows is started, before or after logging on
- 2/ When traffic to the remote network is detected (see chapter 14 Automation)
- 3/ When inserting a USB drive containing the relevant VPN configuration (see chapter 20 USB mode)
- 4/ When inserting the smart card or token containing the certificate used for this tunnel (see section 17.7 Using a certificate stored on a smart card or token)

7 Configuration wizard


The configuration wizard in the Windows Standard VPN Client allows you to configure a VPN tunnel in three easy steps.

The way the configuration wizard works is illustrated in the example below:

- The tunnel is open between a workstation and a VPN gateway that has been assigned the DNS address "myrouter.dyndns.org"
- The company's local network is 192.168.1.0 (it may, for example, include machines that have been assigned the IP addresses 192.168.1.3, 192.168.1.4, etc.)
- Once the tunnel is open, the remote workstation will have the following IP address on the company's network: 10.10.10.10




In the main interface, open the VPN configuration wizard: "Configuration > Configuration Wizard..."



Security recommendation: We recommend configuring IKEv2 tunnels with a certificate. Refer to chapter 24 Security recommendations.

7.1 Step 1

Choose the VPN protocol to be used for the tunnel: IKEv1, IKEv2 or SSL.




The screenshot shows the 'VPN Configuration Wizard' window at step 1/3, titled 'Choice of the remote tunnel type'. The window has a green header bar with the title and step number. Below the header, the text reads 'Please, choose the type of tunnel you would like to create:'. There are three radio button options: 'an IKE V1 Tunnel' (which is selected), 'an IKE V2 Tunnel', and 'an SSL Tunnel'. At the bottom of the window, there are three buttons: '< Previous', 'Next >', and 'Cancel'.

7.2 Step 2

7.2.1 For an IKEv1 VPN tunnel

Enter the following values:

- The IP or DNS address on the internet network side of the VPN gateway (e.g. myrouter.dyndns.org)
- A preshared key that must be configured identically on the gateway
- The IP Address of the company network (e.g. 192.168.1.0). (1)



The screenshot shows the 'VPN Configuration Wizard' window at step 2/3, titled 'VPN tunnel parameters'. The window has a green header bar with the title and step number. Below the header, the text reads 'Enter the following parameters for the VPN tunnel:'. There are three input fields: 'IP or DNS public (external) address: of the remote gateway' with the value 'myrouter.dyndns.org', 'Preshared key:' with a masked value of seven dots, and 'IP private (internal) address: of the remote network' with the value '192 . 168 . 1 . 0'. At the bottom of the window, there are three buttons: '< Previous', 'Next >', and 'Cancel'.

(1) By default, the remote network address used has a prefix length of 24. This value can be modified at a later stage.

7.2.2 For an IKEv2 VPN tunnel

Enter the following values:

- The IP or DNS address on the internet network side of the VPN gateway (e.g. myrouter.dyndns.org)
- A preshared key that must be configured identically on the gateway
- OR: A certificate that must be imported using the "Import Certificate..." button (see section 17.3 Importing a certificate)

The screenshot shows the 'VPN Configuration Wizard' window, step 2/3 titled 'VPN tunnel parameters'. The window contains the following elements:

- Header: 'VPN Configuration Wizard' with a close button (X) and 'VPN tunnel parameters 2/3'.
- Instruction: 'Enter the following parameters for the VPN tunnel:'.
- Field 1: 'IP or DNS public (external) address: of the remote gateway' with the value 'myrouter.dyndns.org'.
- Field 2: 'Preshared key:' with a masked input field containing seven dots.
- Button: 'Import Certificate...'.
- Radio buttons: 'Preshared Key' (selected) and 'Certificate'.
- Navigation buttons: '< Previous', 'Next >', and 'Cancel'.

7.2.3 For an SSL tunnel (OpenVPN)

Enter the following values:


- The IP or DNS address on the internet network side of the VPN gateway (e.g. myrouter.dyndns.org)
- A certificate that must be imported using the "Import Certificate..." button (see section 17.3 Importing a certificate)

The screenshot shows the 'VPN Configuration Wizard' window, step 2/3 titled 'VPN tunnel parameters'. The window contains the following elements:

- Header: 'VPN Configuration Wizard' with a close button (X) and 'VPN tunnel parameters 2/3'.
- Instruction: 'Enter the following parameters for the VPN tunnel:'.
- Field 1: 'IP or DNS public (external) address: of the remote gateway' with the value 'myrouter.dyndns.org'.
- Field 2: 'Certificate Common Name' with the value '<Click the import button>'.
- Button: 'Import Certificate...'.
- Checkbox: 'Login required' (unchecked).
- Navigation buttons: '< Previous', 'Next >', and 'Cancel'.

7.3 Step 3


Review the Summary window to check whether the configuration is correct and then click “Finish”.



The tunnel that has just been configured now appears in the VPN configuration tree of the main interface. Double-click the tunnel to open it or use the tabs of the main interface for further configuration.

8 Connection Panel

The Connection Panel allows you to easily open and close the configured VPN connections:







The Connection Panel can be customized. You can select the VPN connections to be shown. You can also rename or sort the VPN connections.




 Refer to chapter 19 Managing the Connection Panel.

To open a VPN connection, simply click the relevant “OPEN” button.

The icon to the left of the connection name indicates the status of the connection:

-  Connection closed. Click this icon to open the VPN configuration for this connection in the Configuration Panel.
Caution: Access to the Configuration Panel may be restricted (see section 22.1 Displaying/hiding the interface).
-  Connection being opened or closed.
-  Connection open. When there is traffic on this connection, the color intensity of the disk at the center of the icon changes.
-  The connection experienced an incident while opening or closing. Clicking the warning icon will open a pop-up window giving detailed or additional information about the incident.

The Connection Panel buttons are used to perform the following actions:

-  Open the “About...” window
-  Open the Configuration Panel
Caution: Access to the Configuration Panel may be restricted (see section 22.1 Displaying/hiding the interface).
-  Close the Connection Panel

The following keyboard shortcuts are available for the Connection Panel:

- ESC (or ALT+F4) closes the window
- CTRL+ENTER opens the Configuration Panel (main interface)
- CTRL+O opens the selected VPN connection
- CTRL+W closes the selected VPN connection
- The Up and Down arrow keys can be used to navigate up or down the VPN connection list


9 Configuration Panel

The Configuration Panel is the administrator's interface of the Windows Standard VPN Client.

It is accessible to all users, unless the “Restrict access to Configuration Panel to administrator” is enabled (see section 22.1 Displaying/hiding the interface). In this case, the VPN Client must be run as Windows administrator (see paragraph [Running the VPN Client as administrator](#) in section 6.2 Starting the software above).

It includes the following items:

- A set of menus for VPN configuration and software management
- The VPN configuration tree
- VPN tunnel configuration tabs
- A status bar




9.1 Menus


The following menus are available in the Configuration Panel:

- Configuration
 - o Save
 - o Import: [Import a VPN configuration](#)
 - o Export: [Export a VPN configuration](#)
 - o Move to a USB drive: USB mode
 - o [Configuration Wizard](#)
 - o Quit: Close all open VPN tunnels and quit the software
- - Tools
 - o [Connection Panel](#)
 - o [Connections Configuration](#)
 - o Console: IKE connection traces window
 - o Reset IKE: Restart the IKE service
 - o Options: Protection, display, startup, language management, PKI management options
- - ?
 - o Online support: Access to online support
 - o [Updating](#) the software: Check for available updates
 - o Purchase license online: Access the online store
 - o [Activation Wizard...](#)
 - o [About...](#)

9.2 Status bar

The status bar at the bottom of the main interface displays multiple items:



- The “LED” on the left edge is green when all the software’s services are operational (IKE service)
- The text on the left shows the software status (“VPN Client ready”, “Saving configuration”, “Applying configuration”, etc.)
- When the trace mode is enabled, the text “Trace Mode is ON” is shown in the middle of the status bar.
- The  icon, which appears to the left of this text, is a clickable icon that opens the folder containing the log files generated by the trace mode.
- The progress bar on the right side of the status bar shows the progress when saving a configuration.


9.3 Shortcuts

CTRL+S	Save the VPN configuration
CTRL+ENTER	Switch to the Connection Panel
CTRL+D	Open the VPN log “Console” window
CTRL+ALT+R	Restart the IKE service
CTRL+ALT+T	Enable the trace mode (log generation)

9.4 VPN configuration tree

9.4.1 Usage

The left side of the Configuration Panel is the tree structure of the VPN configuration. The tree can contain an infinite number of tunnels.







Under the root called “VPN Configuration”, there are three levels that allow you to create the following respectively:

- IPsec IKEv1 tunnels, specified by a Phase 1 and a Phase 2, knowing that each Phase 1 can contain more than one Phase 2
- IPsec IKEv2 tunnels, specified by an IKE Auth and a Child SA, knowing that each IKE Auth can contain more than one Child SA
- SSL/TLS tunnels

Clicking on a Phase 1, Phase 2, IKE Auth, Child SA, or TLS will open the corresponding VPN configuration tabs on the right-hand side of the Configuration Panel. See the following sections for further details:

1. IPsec IKEv1 VPN tunnel
 - [IKEv1 \(Phase 1\): Authentication](#)
 - [IKEv1 \(Phase 2\): IPsec](#)
2. IPsec IKEv2 VPN tunnel
 - [IKEv2 \(IKE Auth\): Authentication](#)
 - [IKEv2 \(Child SA\): IPsec](#)
3. SSL VPN tunnel
 - [SSL: TLS](#)

An icon is associated with each tunnel (Phase 2, Child SA or TLS). This icon shows the status of the VPN tunnel:

-  Tunnel is closed
-  Tunnel is being opened
-  Tunnel is open
-  Incident when opening or closing the tunnel

You can edit and change the name of any item in the tree by clicking twice in a row on it, without double-clicking.

If there are any unsaved changes in the VPN configuration, the modified item is shown in bold. As soon as the tree is saved, all text formatting is removed.




Two items in the tree cannot have the same name. The software displays a message to the user if the name entered is already in use.

9.4.2 Contextual menus

1. VPN configuration

Right clicking the VPN configuration (root of the tree) displays the following contextual menu:



Export	Used to export the complete VPN configuration .
Move to USB drive...	Moves the VPN configuration to a USB drive and initiates USB mode .
Save	Used to save the VPN configuration.
Configuration wizard	Opens the VPN Configuration Wizard .
Reload default configuration	The Windows Standard VPN Client comes with a default VPN configuration that can be used to test opening a VPN tunnel. This menu is used to reload the default configuration at any time.
Reset	Resets the VPN configuration following confirmation by the user.
Close all tunnels	Closes all open tunnels.

2. IKEv1, IKEv2, SSL


Right clicking the IKEv1, IKEv2 or SSL items will display the following contextual menu, which allows you to export, save, create, or paste a Phase 1/IKE Auth/SSL:



IKEv1 menu



IKEv2 menu



SSL menu

Export	Used to export all IKEv1 tunnels (resp. all IKEv2 tunnels)
Save	Used to save all IKEv1 tunnels (resp. all IKEv2 tunnels)
New Phase 1 New IKE Auth New TLS	Used to create a new Phase 1/IKE Auth/TLS. The parameters of this new Phase 1/IKE Auth/TLS will be filled in with default values.

Paste Phase 1	Adds a Phase 1/IKE Auth/TLS that has been previously copied to the clipboard.
Paste IKE Auth	
Paste TLS	

(1) This choice will be shown when a Phase 1/IKE Auth/TLS has been copied to the clipboard using the contextual menu associated with the Phase 1/IKE Auth/TLS (see below).

3. Phase 1 or IKE Auth

Right-clicking a Phase 1 or IKE Auth displays the following contextual menu:

Copy	Ctrl+C	Copy	Ctrl+C
Rename	F2	Rename	F2
Delete	Del	Delete	Del
New Child SA	Ctrl+N	New Phase 2	Ctrl+N
Paste Child SA	Ctrl+V	Paste Phase 2	Ctrl+V

Copy	Copies the selected Phase 1 or IKE Auth to the clipboard.
Rename (1)	Used to rename the Phase 1/IKE Auth.
Delete (1)	Used to delete the selected Phase 1 or IKE Auth following confirmation by the user, including every corresponding Phase 2 (resp. Child SA).
New Phase 2 New Child SA	Adds a new Phase 2/Child SA to the selected Phase 1/IKE Auth.
Paste Phase 2 (2) Paste Child SA	Adds the Phase 2/Child SA that has been copied to the clipboard to the Phase 1/IKE Auth.

- (1) This menu is disabled as long as one of the tunnels of the relevant Phase 1/IKE Auth is open.
 (2) This choice will be shown when a Phase 2/Child SA has been copied to the clipboard using the contextual menu associated with the Phase 2/Child SA (see below).

4. Phase 2, Child SA, or TLS

Right-clicking a Phase 2, Child SA, or TLS displays the following contextual menu:

Open tunnel	Ctrl+O	Close tunnel	Ctrl+W
Export		Export	
Copy	Ctrl+C	Copy	Ctrl+C
Rename	F2	Rename	F2
Delete	Del	Delete	Del

Menu with tunnel closed

Menu with tunnel open

Open tunnel	Displayed if the VPN tunnel is closed and is used to open the selected tunnel (Phase 2, Child SA, or TLS)
Close tunnel	Displayed if the VPN tunnel is open and is used to close the selected tunnel (Phase 2, Child SA, or TLS)

Export (1)	Used to export the selected Phase 2, Child SA, or TLS
Copy	Used to copy the selected Phase 2, Child SA, or TLS
Rename (2)	Used to rename the selected Phase 2, Child SA, or TLS
Delete (2)	Used to delete the selected Phase 2, Child SA, or TLS following confirmation by the user

(1) This function allows users to export the entire tunnel, i.e. both the Phase 2 and the corresponding Phase 1 (resp. Child SA and its associated IKE Auth, or TLS), and thus to create a fully operational, single-tunnel VPN configuration (which becomes immediately functional when imported).

(2) This menu is disabled while the tunnel is open.

9.4.3 Shortcuts


The following shortcuts are available for tree management:

F2	Used to edit the name of the selected Phase
DEL	Used to delete a selected phase, following confirmation by the user. If the actual VPN configuration is selected (root of the tree), the software asks whether a full reset of the configuration should be performed.
CTRL+O	Opens the corresponding VPN tunnel if a Phase 2/Child SA/TLS is selected.
CTRL+W	Closes the corresponding VPN tunnel if a Phase 2/Child SA/TLS is selected.
CTRL+C	Copies the selected phase to the clipboard.
CTRL+V	Pastes (adds) the phase that has previously been copied to the clipboard.
CTRL+N	If the VPN configuration is selected, creates a new Phase 1/IKE Auth. If a Phase 1/IKE Auth is selected, creates a Phase 2/Child SA/TLS.
CTRL+S	Saves the VPN configuration.

10 “About...” window

The “About...” window can be accessed as follows:

- Click the “?” menu in the Configuration Panel and choose “About...”.
- Use the system menu in the Configuration Panel.
- Click the [?] button in the Connection Panel.



The “About...” window displays the following information:

- The name and version number of the software
 - A web link to TheGreenBow’s website
 - When the software is activated, the license number and e-mail used for activation
 - During the software trial period, the number of days remaining before the trial period expires
 - The version numbers of all software components (1)
- (1) You can select and copy the contents of the entire list of version numbers (right-click on the list and choose “Select all”), for example to send the information for analysis purposes. When the “About” window is open, if the Windows Standard VPN Client has not been activated, the software tries to connect to the activation server to validate the license.

11 Importing and exporting the VPN configuration

11.1 Importing a VPN configuration

The Windows Standard VPN Client allows you to import a VPN configuration. To do this, from the “Configuration” menu in the Configuration Panel (main interface), choose “Import”



As of version 6.8 of the Windows Standard VPN Client, dragging and dropping a VPN configuration file (.tgb file) onto the Configuration Panel is no longer supported, because privilege elevation is now required to manage VPN configurations.




As of version 6.8 of the Windows Standard VPN Client, the function that allows you to double-click on a configuration file to import it is no longer available.




The Windows Standard VPN Client does not monitor VPN configuration file integrity. No signature is generated during an export and no check is performed for a possible signature during an import.


When importing a VPN configuration, users are prompted to specify whether they want to add the new VPN configuration to the current one or replace (overwrite) the current configuration with the new one:



If the imported VPN configuration has been exported with a password protection (see section 11.2 Exporting a VPN configuration below), users will have to provide the password.



If one or several tunnels are open when importing, the following information window will be displayed to let you know that the import will close all open tunnels:



Once this message has been confirmed and the import has been completed, you will need to reopen the tunnels.



If some of the VPN tunnels added have the same name as certain tunnels in the current configuration, they are automatically renamed during import (an increment will be added between brackets).

Importing IKEv1 parameters

If the user chooses “Replace” during an import or if the current configuration is empty, the IKEv1 parameters of the imported VPN configuration will replace the IKEv1 parameters of the current configuration.

If the user chooses “Add” during an import, the IKEv1 parameters of the current VPN configuration are preserved.

User's choice during import	Current VPN configuration is empty	Current VPN configuration is not empty
Add	IKEv1 parameters are replaced with the new ones	IKEv1 parameters are preserved
Replace	IKEv1 parameters are replaced with the new ones	IKEv1 parameters are replaced with the new ones

11.2 Exporting a VPN configuration


The Windows Standard VPN Client allows you to export a VPN configuration in various ways:

- 1/ From the “Configuration” menu, choose “Export”: the complete VPN configuration is exported.
- 2/ Contextual menu at the root of the VPN configuration tree > Export: the complete VPN configuration is exported.
- 3/ Contextual menu associated with a Phase 1 (IKEv1) or an IKE Auth (IKEv2) > Export: the entire Phase 1/IKE Auth (including all Phase 2/Child SA it contains) is exported.
- 4/ Contextual menu associated with a Phase 2 (IKEv1) or a Child SA (IKEv2) > Export: the Phase 2/Child SA is exported along with the Phase 1/IKE Auth with which it is associated.
- 5/ Contextual menu associated with a TLS > Export: the TLS is exported.



By default, the extension of exported VPN configuration files is `.tgb`.

Regardless of the method used, the export starts with the choice of protection for the exported VPN configuration: it can be exported with (encryption) or without (clear text) password protection. If a password has been set, users will be required to enter it when importing.



We recommend that you always export VPN configurations with a password protection (encrypted).

11.3 Merging VPN configurations

Several configurations can be merged by successively importing all VPN configurations and choosing “Add” each time (see section 11.1 Importing a VPN configuration above).

11.4 Splitting a VPN configuration

Using the various export options available (exporting a Phase 1/IKE Auth/TLS with all the corresponding Phase 2/Child SA/TLS or exporting a single tunnel), a VPN configuration can be split into as many “sub-configurations” as desired (see section 11.2 Exporting a VPN configuration below).

This method can be used to deploy the configurations for a pool of workstations: derive the VPN configurations for each individual workstation from a common VPN configuration prior to sending them to each user for import.

12 Configuring a VPN tunnel

12.1 IPsec IKEv1, IPsec IKEv2 or SSL VPN

The Windows Standard VPN Client allows you to create and configure several types of VPN tunnels. It also allows you to open them simultaneously.

The Windows Standard VPN Client allows you to configure the following types of tunnels:

- IPsec IKEv1
- IPsec IKEv2
- SSL

The procedure used to create a new VPN tunnel is described in the previous sections: 7 Configuration wizard and 9.4.2 Contextual menus.



Security recommendation: We recommend configuring IKEv2 tunnels with a certificate. Refer to chapter 24 Security recommendations.

12.2 Editing and saving a VPN configuration

The Windows Standard VPN Client allows you to edit the VPN tunnels and to test your changes “on-the-fly” without needing to save the VPN configuration.

All unsaved changes in the VPN configuration are clearly shown in the tree, as the name of modified items appears in bold.

The VPN configuration can be saved at any time using either of the following:

- CTRL+S shortcut
- “Configuration > Save” menu item

A warning will be displayed if a VPN configuration has been changed and the user tries to quit the software without saving.

12.3 Configuring an IPsec IKEv1 tunnel

12.3.1 Phase 1: Authentication

Addresses

Interface IP address of the network interface on which the VPN connection is open. You can let the software automatically decide which interface to use by selecting "Any".

We recommend choosing this option if the tunnel being configured is to be deployed on a different workstation.

Remote Gateway IP address (IPv4 or IPv6) or DNS address of the remote VPN gateway. This field is mandatory.

Authentication

Preshared key

Password or key shared by the remote gateway.



The preshared key is an easy way to configure a VPN tunnel. However, it is less flexible in terms of security management than the use of certificates.
Refer to chapter 24 Security recommendations.

Certificate

Use of certificates for VPN connection authentication.



Using Certificate strengthens the security in terms of VPN connection management (mutual authentication, verification of validity periods, revocation, etc.)
Refer to chapter 24 Security recommendations.



Refer to the dedicated chapter: 17 Managing certificates.

X-Auth management

X-Auth is an extension of the IKE protocol (Internet Key Exchange).

The X-Auth function is used to force the entry of a login name and password to open a VPN tunnel.



This requires a similar configuration to be set up on the VPN gateway.

X-Auth

Enabled

X-Auth Popup

Login

Once

Password



Hybrid Mode

If the “X-Auth Popup” box is checked, a popup window prompting the user to enter a login name and authentication password will be shown each time a VPN tunnel is opened (the window prompting for a login name and password will have the same name as the tunnel to avoid any confusion).


This window has a timeout limit (which can be set in the [IKEv1 parameters](#)). When the timeout expires, a warning is displayed prompting the user to re-open the tunnel.

The VPN Client can store the X-Auth login name and password in the VPN configuration. If this is the case, the login name and password will be automatically sent to the VPN gateway when the tunnel is opened.

X-Auth

Enabled X-Auth Popup

Login Once

Password  Hybrid Mode

This option facilitates the use and deployment of the software. However, it is considered a less secure option than displaying a dynamic X-Auth login window.



We recommend that you do not store the X-Auth login and password in the VPN configuration. Refer to chapter 24 Security recommendations.

Check the “Once” option to avoid having to enter the password again during a Phase 1 renegotiation.


The Hybrid mode “mixes” two different types of authentication: standard VPN gateway authentication and X-Auth authentication for the VPN Client.

To activate the Hybrid mode, the tunnel must be associated with a certificate (see chapter 17 Managing certificates) and the X-Auth function must be configured.

X-Auth

Enabled X-Auth Popup

Login Once

Password  Hybrid Mode

Cryptography

Encryption	Encryption algorithm negotiated during the authentication phase (1): Auto (2), AES-128, AES-192, AES-256.
Authentication	Authentication algorithm negotiated during the authentication phase (1): Auto (2), SHA2-256, SHA2-384, SHA2-512.
Key group	Length of Diffie-Hellman key (1): Auto (2), DH14 (2048), DH15 (3072), DH16 (4096), DH17 (6144), DH18 (8192)

(1) Refer to chapter 24 Security recommendations on the choice of algorithm.

(2) Auto means that the VPN Client automatically adapts to the gateway parameters. When “Auto” is selected, the following algorithms (and their various combinations) are supported:

- Encryption: AES-128, AES-192
- Authentication: SHA2-256, SHA2-384, SHA2-512
- Key group: DH14 (2048), DH15 (3072), DH16 (4096)

If the gateway has been configured using a different algorithm, then the “Auto” mode cannot be used. The algorithm must be specified explicitly in the VPN Client.



12.3.2 Phase 1: Protocol

The screenshot shows the 'Protocol' tab of the VPN Client configuration. Under the 'Identity' section, 'Local ID' is set to 'DER ASN1 DN' and 'Remote ID' is empty. Under 'Advanced features', 'Fragmentation' is unchecked, 'Fragment size' is empty, 'IKE Port' is 500, 'NAT Port' is 4500, 'Enable NATT offset' is unchecked, and 'Childless' is unchecked.

Identity

Local ID	<p>Local ID is the authentication phase (Phase 1) identifier that the VPN Client sends to the remote VPN gateway.</p> <p>According to the type selected, this identifier can be any of the following:</p> <ul style="list-style-type: none"> - IP address: an IPv4 address (type = IPV4 ADDR), e.g. 195.100.205.101 - DNS: a domain name (type = FQDN), e.g. gw.mydomain.net - KEY ID: a character string (type = KEY ID), e.g. 123456 - Email: an e-mail address (type = USER FQDN), e.g. support@thegreenbow.com - DER ASN1 DN: the X.509 subject of a certificate (type = DER ASN1 DN) - X509 subject: this field is automatically filled in with the subject of an X.509 certificate when the tunnel is associated with a user certificate (see chapter 17 Managing certificates) <p>If this parameter is not set, the VPN Client's IP address is used by default.</p>
Remote ID	<p>Remote ID is the identifier that the VPN Client expects to receive from the VPN gateway.</p> <p>According to the type selected, this identifier can be any of the following:</p> <ul style="list-style-type: none"> - IP address: an IP address (type = IPV4 ADDR), e.g. 80.2.3.4 - DNS: a domain name (type = FQDN), e.g. router.mydomain.com - KEY ID: a character string (type = KEY ID), e.g. 123456 - Email: an e-mail address (type = USER FQDN), e.g. admin@mydomain.com - DER ASN1 DN: the X.509 subject of a certificate (type = DER ASN1 DN) <p>This setting is required since version 6.8 for security reasons.</p>

Advanced features

Fragmentation/ Fragment size	This function enables IKE fragmentation, which prevents packets from becoming fragmented (and potentially blocked) by the IP network they're passing through. We recommend that you enable this option (both on the gateway and on the VPN Client) in case the internet service provider has set up carrier-grade NAT (CGN), which prevents fragmentation from working at the IP level. The fragment size must generally be set to a value that is smaller by 200 bytes than the MTU of the physical interface, e.g. 1300 bytes for a typical 1500-byte MTU.						
IKE Port	IKE Phase 1 (Authentication) exchanges use the UDP protocol and port 500 by default. IKE port configuration can bypass the networking hardware (firewalls, routers) that filter port 500. <div style="border: 1px solid #0070C0; background-color: #D9E1F2; padding: 5px; margin-top: 10px;">  The remote VPN gateway must also be able to perform the IKE Phase 1 exchanges on a port other than 500. </div>						
NAT Port	IKE Phase 2 (IPsec) exchanges use the UDP protocol and port 4500 by default. NAT port configuration can bypass the networking hardware (firewalls, routers) that filter port 4500. <div style="border: 1px solid #0070C0; background-color: #D9E1F2; padding: 5px; margin-top: 10px;">  The remote VPN gateway must also be able to perform the IKE Phase 2 exchanges on a port other than 4500. </div>						
Enable NATT offset	When the IKE port is different from 500, it may be necessary to check this option for the gateway to accept the connection.						
Mode Config	Once it is activated, Mode Config enables the VPN Client to get the configuration data required to open the VPN tunnel from the VPN gateway. See the following paragraph below: Managing Mode Config.						
Aggressive mode	The VPN Client uses the Aggressive mode to connect to the VPN gateway.						
NAT-T	<p>"NAT-Traversal" mode.</p> <p>The VPN Client can handle three types of NAT-T modes:</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">Disabled</td> <td>Prevents the VPN Client and the VPN gateway to switch to NAT-Traversal mode.</td> </tr> <tr> <td>Automatic</td> <td>Lets the VPN Client and the VPN gateway negotiate the NAT-Traversal mode.</td> </tr> <tr> <td>Forced</td> <td>The VPN Client will force the NAT-T mode by systematically encapsulating IPsec packets into UDP frames. This will solve NAT-Traversal issues using intermediate routers.</td> </tr> </table>	Disabled	Prevents the VPN Client and the VPN gateway to switch to NAT-Traversal mode.	Automatic	Lets the VPN Client and the VPN gateway negotiate the NAT-Traversal mode.	Forced	The VPN Client will force the NAT-T mode by systematically encapsulating IPsec packets into UDP frames. This will solve NAT-Traversal issues using intermediate routers.
Disabled	Prevents the VPN Client and the VPN gateway to switch to NAT-Traversal mode.						
Automatic	Lets the VPN Client and the VPN gateway negotiate the NAT-Traversal mode.						
Forced	The VPN Client will force the NAT-T mode by systematically encapsulating IPsec packets into UDP frames. This will solve NAT-Traversal issues using intermediate routers.						

Managing Mode Config

Once it is activated, Mode Config enables the VPN Client to get the configuration data required to open the VPN tunnel from the VPN gateway:

- Virtual IP address of the VPN Client
- DNS server address (optional)
- WINS server address (optional)



Mode Config will only be operational if the VPN gateway supports it.

When Mode Config is disabled, the three items “VPN Client address”, “DNS server” and “WINS server” can be configured manually in the VPN Client (see sections 12.3.6 Phase 2: IPsec and 12.3.7 Phase 2: Advanced).

Similarly, when Mode Config is enabled, the Phase 2 fields “VPN Client address”, “DNS server” and “WINS server” will be automatically filled in when a VPN tunnel is opened. Therefore, no data can be entered in them (they are grayed out).

12.3.3 Phase 1: Gateway

Dead Peer Detection (DPD)

Dead Peer Detection

The Dead Peer Detection (DPD) function enables the VPN Client to detect whether the VPN gateway has become unreachable or inactive. (1)

- Check interval: Time interval between two DPD check messages, expressed in seconds.
- Max. number of retries: Number of consecutive unsuccessful attempts before concluding that the VPN gateway is unreachable.
- Delay between retries: Time between two DPD messages when the VPN gateway is not responding, expressed in seconds.


(1) The DPD function is activated once the tunnel is open (phase 1 established). When linked to a redundant gateway, DPD allows the VPN Client to automatically switch between gateways when one of them is unavailable.

Lifetime


Lifetime	Lifetimes are negotiated when the tunnel is established. (1) When the lifetime is reached, the Phase 1 will be renegotiated. The default value for the lifetime of the Phase 1 is 2700 s (45 min).
----------	--

(1) Lifetimes are negotiated between the VPN Client and the VPN gateway. However, some gateways simply return the lifetime value suggested by the VPN Client. Regardless of the method used, the VPN Client will always apply the lifetime value sent by the VPN gateway.

Gateway-related parameters

Redundant gateway	Defines the address of a spare VPN gateway that the VPN Client will switch to when the initial gateway is unavailable or unreachable. The address of the redundant VPN gateway can be either an IP or a DNS address.  Refer to chapter 13 Redundant gateway.
Retransmissions	Number of IKE protocol message resent when the gateway is not responding. Once this number of retransmission attempts is reached, the tunnel is declared as failing.

12.3.4 Phase 1: Certificate

 Refer to chapter 17 Managing certificates.

12.3.5 Phase 2

Phase 2 of a VPN tunnel is the IPsec phase. The purpose of this Phase is to negotiate the security parameters that will be applied to the data going through the VPN tunnel.

In order to configure the Phase 2 parameters, select the relevant Phase 2 in the VPN configuration tree. The parameters can be configured in the right-hand tabs of the Configuration Panel.

If any changes are made to a tunnel, they will appear in bold in the VPN configuration tree. You do not need to save a VPN configuration for it to be taken into account. The tunnel can be tested with the modified configuration immediately.

12.3.6 Phase 2: IPsec

IPsec **Advanced** Automation Remote Sharing **IPV4** IPV6

Addresses

VPN Client address

Address type

Remote LAN address

Subnet mask

ESP

Encryption

Authentication

Mode

PFS

PFS Group

Lifetime

IPsec Lifetime sec.

Addresses

VPN Client address	<p>“Virtual” IP address of the workstation, the way it will be “seen” on the remote network.</p> <p>From a technical standpoint, it is the source IP address of the IP packets going through the IPsec tunnel.</p> <p>When the field is set to “0.0.0.0” the software will use the workstation’s physical IP address automatically for the virtual IP address provided to the gateway.</p>
--------------------	--



When [Mode Config](#) is enabled, this field will be grayed out (uneditable). It is automatically filled in when the tunnel is opened with the value sent by the VPN gateway during the Mode Config exchange.

Address type	<p>The endpoint of the tunnel can be a network or a remote workstation.</p> <p> To find out how to configure the address type, refer to the paragraph entitled Configuring the address type below.</p>
--------------	--

ESP

Encryption	Encryption algorithm negotiated during the IPsec phase (1): Auto (2), AES-128, AES-192, AES-256.
Authentication	Authentication algorithm negotiated during the IPsec phase (1): Auto (2), SHA2-256, SHA2-384, SHA2-512.
Mode	IPsec encapsulation mode: Tunnel or Transport (1)

(1) Refer to chapter 24 Security recommendations on the choice of algorithm.

(2) Auto means that the VPN Client automatically adapts to the gateway parameters.

PFS

PFS - Group	Can be enabled or disabled. Length of Diffie-Hellman key: DH14 (2048), DH15 (3072), DH16 (4096), DH17 (6144), DH18 (8192)
-------------	--

IKEv1 does not have an automatic mode for the DH group. It must be specified beforehand.
Refer to chapter 24 Security recommendations on the choice of algorithm.

Lifetime

Lifetime	<p>Lifetimes are negotiated when the tunnel is established. (1)</p> <p>When the lifetime is reached, the Phase 2 will be renegotiated.</p> <p>The default value for the lifetime of Phase 2 is 1800 s (30 min).</p>
----------	---

(1) Lifetimes are negotiated between the VPN Client and the VPN gateway. However, some gateways simply return the lifetime value suggested by the VPN Client. Regardless of the method used, the VPN Client will always apply the lifetime value sent by the VPN gateway.

IPv4 / IPv6

IPv4-IPv6



Refer to chapter 16 IPv4 and IPv6.

Configuring the address type

If the endpoint of the tunnel is a network, choose the “Subnet address” type and then enter the Remote LAN address and Subnet mask:

Address type	Subnet address <input type="text"/>
Remote LAN address	192 . 168 . 175 . 0 <input type="text"/>
Subnet mask	255 . 255 . 255 . 0 <input type="text"/>

As an alternative, you can also select “Range address” and enter the Start and End addresses:

Address type	Range address <input type="text"/>
Start address	192 . 168 . 175 . 1 <input type="text"/>
End address	192 . 168 . 175 . 10 <input type="text"/>

If the endpoint of the tunnel is a workstation, choose the “Single address” type and then enter the Remote host address:

Address type	Single address <input type="text"/>
Remote host address	192 . 168 . 175 . 1 <input type="text"/>



The function “[Automatically open this tunnel on traffic detection](#)” is used to automatically open a tunnel when traffic with one of the addresses specified in the address range is detected (provided that this address range is authorized in the VPN gateway configuration).



If the IP address of the VPN Client workstation is included in the address range for a remote network (e.g. @workstation IP=192.168.10.2 and @remote network=192.168.10.x), then opening a tunnel will prevent the workstation from communicating on the local network. All communications will go through the VPN tunnel.



“All traffic through the VPN tunnel” configuration

The VPN Client can be configured so that all the workstation's outbound traffic goes through the VPN tunnel. To implement this function, select “Subnet address” as the address type and enter “0.0.0.0” as the Remote LAN address and Subnet mask.



Several VPN Client configuration guides for various VPN firewalls/gateways are available on our website at: <https://www.thegreenbow.com/en/support/integration-guides/compatible-vpn-routers/>.

12.3.7 Phase 2: Advanced

Child SA Advanced Automation Remote Sharing **IPV4** IPV6

Alternate servers

DNS Suffix: dev.corporate

Type	IP Address
WINS	192.168.175.2

Buttons: Add DNS, Add WINS

Tunnel traffic check

Period and IP Address of the remote host to ping:

IPV4 Address: 0 . 0 . 0 . 0

Check interval: 0 sec.

Miscellaneous

Disable Split Tunneling


Alternate servers

DNS Suffix	Domain extension added to each machine name, for example: "mozart.dev.corporate". This is an optional parameter: When it is specified, the VPN Client will try to translate the machine address without adding the DNS suffix. However, if translation fails, the DNS suffix will be added and the Client will try to translate the address again.
Alternate servers	Table containing the IP addresses of the DNS (maximum 2) and WINS (maximum 2) servers available on the remote network. The IP addresses will be IPv4 or IPv6 addresses depending on the network type configured in the "IPsec" tab.



When [Mode Config](#) is enabled, these fields will be grayed out (uneditable). They are automatically filled in when the tunnel is opened with the values sent by the VPN gateway during the Mode Config exchange.

Tunnel traffic check

IP address	<p>The VPN Client can be configured so that connectivity to the remote network is checked on a regular basis. If connectivity has been lost, the VPN Client will automatically close the tunnel and attempt to open it again.</p> <p>The IPv4/IPv6 field is the address of a machine within the remote network, which should reply to pings sent by VPN Client. If a ping goes unanswered, the connection is considered lost.</p>
	
<p>If the tunnel is configured in IPv4 (see the button at the top right of the tab), then the IPv4 field is displayed. If the tunnel is configured in IPv6, then the IPv6 field is displayed.</p>	
Check interval	<p>The “Check interval” indicates the time interval in seconds between two pings sent by the VPN Client to the machine with the IP address specified above.</p>

12.3.8 Phase 2: Automation



Refer to chapter 14 Automation.

12.3.9 Phase 2: Remote sharing



Refer to chapter 18 Remote Desktop Sharing.

12.3.10 IKEv1 parameters

IKEv1 parameters are common to all IKEv1 tunnels (every Phase 1 and every Phase 2).

IKE V1 Parameters




Miscellaneous

Retransmissions	<input type="text" value="2"/>	IKE Port	<input type="text"/>
X-Auth timeout	<input type="text" value="60"/>	NAT Port	<input type="text"/>

Disable Split Tunneling

Miscellaneous

Retransmissions	Number of IKE protocol message resends before failure.
X-Auth timeout	Time allowed to enter X-Auth login/password


IKE Port	This field is used to configure the IKE port for all IKEv1 tunnels.
	 The IKE ports that can be configured in every tunnel have the priority over this parameter.
NAT Port	This field is used to configure the NAT port for all IKEv1 tunnels.
	 NAT ports that can be configured in every tunnel have the priority over this parameter.
Disable Split Tunneling	When this option is selected, only the traffic going through the tunnel is authorized.
	 See note (1) below.

The “Disable Split Tunneling” configuration option increases the “leakproofness” of the workstation, provided that the VPN tunnel is open. More specifically, this function eliminates the risk of incoming data flows that do not go through the VPN tunnel.

Combined with the “All traffic through the VPN tunnel” configuration (see section 12.3.6Phase 2: IPsec), this option guarantees the complete leakproofness of the workstation provided the VPN tunnel is open.


12.4 Configuring an IPsec IKEv2 tunnel

12.4.1 IKE Auth: Authentication



Addresses

Interface Name of the network interface on which the VPN connection is open. You can let the software automatically decide which interface to use by selecting "Any".



We recommend choosing this option if the tunnel being configured is to be deployed on a different workstation.

In case several IP addresses are assigned to the network interface, you can specify a specific IP address or subnet to be used. To do this, add the "local_subnet" dynamic parameter on the "IKE Auth" tab (see Displaying more parameters in section 22.2 General) and define its value to the IP address of the desired subnet using the aaa.bbb.ccc.ddd/xx format, e.g. 192.168.0.0/24 to specify the 192.168.0.1 – 192.168.0.255 subnet. To specify a single IP address, use the value 32 for the subnet mask, e.g. 192.168.0.2/32 to specify the IP address 192.168.0.2.



This last feature is only available for IPv4.

Remote Gateway IP (IPv4 or IPv6) or DNS address of the remote VPN gateway. This field is mandatory.

Authentication

Preshared key Password or key shared by the remote gateway.



The preshared key is an easy way to configure a VPN tunnel. However, it is less flexible in terms of security management than the use of certificates. Refer to chapter 24 Security recommendations.

Certificate Use of certificates for VPN connection authentication.



Using certificates strengthens the security in terms of VPN connection management (mutual authentication, verification of validity periods, cancellation, etc.) Refer to chapter 24 Security recommendations.



Refer to the dedicated chapter: 17 Managing certificates.

EAP	<p>The Extensible Authentication Protocol (EAP) mode is used to authenticate the user based on a login name and password. When the EAP mode is selected, a popup window will prompt the user to enter a login name and password every time the tunnel is opened.</p> <p>When the EAP mode is selected, you can choose to display a prompt for the EAP login name and password every time the tunnel is opened (using the “EAP popup” checkbox) or to store them in the VPN configuration by entering them in the Login and Password fields.</p> <p>We recommend not to use the latter mode, see chapter 24 Security recommendations).</p>
Multiple AUTH support	Enables the combination of certificate and EAP authentications. (1)

- (1) The VPN Client supports “Certificate then EAP” double authentication.
The VPN Client does not support “EAP then Certificate” double authentication.

Cryptography

Encryption	Encryption algorithm negotiated during the authentication phase (1): Auto (2), AES CBC (128, 192, 256), AES CTR (128, 192, 256), AES GCM (128, 192, 256).
Authentication	Authentication algorithm negotiated during the authentication phase (1): Auto (2), SHA2 256, SHA2 384, SHA2 512.
Key group	Length of Diffie-Hellman key (1): Auto (2), DH14 (MODP 2048), DH15 (MODP 3072), DH16 (MODP 4096), DH17 (MODP 6144), DH18 (MODP 8192), DH19 (ECP 256), DH20 (ECP 384), DH21 (ECP 521).

- (1) Refer to chapter 24 Security recommendations on the choice of algorithm.
(2) Auto means that the VPN Client automatically adapts to the gateway parameters.

12.4.2 IKE Auth: Protocol

The screenshot shows the 'Authentication' tab of the IKE Auth: Protocol configuration window. It features the following elements:

- Identity section:**
 - Local ID: A dropdown menu and a text input field.
 - Remote ID: A dropdown menu and a text input field.
- Advanced features section:**
 - Fragmentation:
 - Fragment size: A text input field.
 - IKE Port: A text input field containing '500'.
 - NAT Port: A text input field containing '4500'.
 - Childless:
 - Enable NATT offset:

Identity

Local ID Local ID is the identifier that the VPN Client sends to the remote VPN gateway during the authentication phase.

According to the type selected, this identifier can be any of the following:

- IP address: an IPv4 address (type = IPV4 ADDR), e.g. 195.100.205.101
- DNS: a domain name (type = FQDN), e.g. gw.mydomain.net
- KEY ID: a character string (type = KEY ID), e.g. 123456
- Email: an e-mail address (type = USER FQDN), e.g. support@thegreenbow.com
- DER ASN1 DN: the X.509 subject of a certificate (type = DER ASN1 DN)
- X509 subject: this field is automatically filled in with the subject of an X.509 certificate when the tunnel is associated with a user certificate (see chapter 17Managing certificates)

If this parameter is not set, the VPN Client's IP address is used by default.

Remote ID Remote ID is the identifier that the VPN Client expects to receive from the VPN gateway.

According to the type selected, this identifier can be any of the following:

- IP address: an IP address (type = IPV4 ADDR), e.g. 80.2.3.4
- DNS: a domain name (type = FQDN), e.g. router.mydomain.com
- KEY ID: a character string (type = KEY ID), e.g. 123456
- Email: an e-mail address (type = USER FQDN), e.g. admin@mydomain.com
- DER ASN1 DN: the X.509 subject of a certificate (type = DER ASN1 DN)

This setting is required since version 6.8 for security reasons.

Advanced features

IKEv2 fragmentation Enables IKEv2 packet fragmentation in accordance with RFC 7383. This function prevents IKEv2 packets from being fragmented by the IP network they're passing through. The fragment size must generally be set to a value that is smaller by 200 bytes than the MTU of the physical interface, e.g. 1300 bytes for a typical 1500-byte MTU.

IKE Port IKE Auth (Authentication) exchanges use the UDP protocol and port 500 by default. IKE port configuration can bypass the networking hardware (firewall, routers) that filter port 500.



The remote VPN gateway must also be able to perform the IKE Auth exchanges on a port other than 500.


NAT Port IKE Child SA (IPsec) exchanges use the UDP protocol and port 4500 by default. NAT port configuration can bypass the networking hardware (firewall, routers) that filter port 4500.



The remote VPN gateway must also be able to perform the IKE Child SA exchanges on a port other than 4500.

Enable NATT offset	When the IKE port is different from 500, it may be necessary to check this option for the gateway to accept the connection.
Childless	When this mode is enabled, the VPN Client will attempt to initiate IKE exchanges without creating any Child SA in accordance with RFC 6023. We recommend using this mode.

12.4.3 IKE Auth: Gateway



Dead Peer Detection (DPD)


Check interval	The Dead Peer Detection (DPD) function enables the VPN Client to detect whether the VPN gateway has become unreachable or inactive. (1) The check interval is the time period between two consecutive DPD check messages sent, expressed in seconds.
Max. number of retries	Number of consecutive unsuccessful attempts before concluding that the VPN gateway is unreachable.
Delay between retries	Time between two DPD messages when the VPN gateway is not responding, expressed in seconds.

(1) The DPD function is enabled upon opening the tunnel (after the authentication phase). When linked to a redundant gateway, DPD allows the VPN Client to automatically switch between gateways when one of them is unavailable.

Lifetime

Lifetime	Lifetime of the IKE Authentication phase. The lifetime is expressed in seconds. The default value is 1800 seconds.
----------	--

Gateway-related parameters

Redundant gateway	Used to define the address of a spare VPN gateway that the VPN Client will switch to when the initial gateway is unavailable or unreachable. The address of the redundant VPN gateway can be either an IP or a DNS address.  Refer to chapter 13 Redundant gateway.
Retransmissions	Number of IKE protocol message resends before failure.
Gateway timeout	Delay between two retransmissions

12.4.4 IKE Auth: Certificate

 Refer to chapter: 17 Managing certificates.


12.4.5 Child SA: Overview

The Child SA of a VPN tunnel is the IPsec phase. The purpose of this phase is to negotiate the security parameters that will be applied to the data going through the VPN tunnel.

To configure Child SA parameters, select the Child SA in the VPN configuration tree. The parameters can be configured in the right-hand tabs of the Configuration Panel.

If any changes are made to a tunnel, they will appear in bold in the VPN configuration tree. You do not need to save a VPN configuration for it to be taken into account. The tunnel can be tested with the modified configuration immediately.

12.4.6 Child SA: Child SA



Child SA | Advanced | Automation | Remote Sharing | **IPV4** | IPV6

Traffic selectors

VPN Client address: 10 . 60 . 60 . 20

Address type: Subnet address

Remote LAN address: 192 . 168 . 175 . 0

Subnet mask: 255 . 255 . 255 . 0

Request configuration from the gateway

Cryptography

Encryption: Auto

Integrity: Auto




Diffie-Hellman: Auto

Extended Sequence Number: No

Lifetime

Child SA Lifetime: 1800 sec.

Traffic selectors

VPN Client address	<p>“Virtual” IP address of the workstation, the way it will be “seen” on the remote network.</p> <p>From a technical standpoint, it is the source IP address of the IP packets going through the IPsec tunnel.</p>
Address type	<p>The endpoint of the tunnel can be a network or a remote workstation.</p> <p> To find out how to configure the address type, refer to the paragraph entitled Configuring the address type below.</p>
Request configuration from the gateway	<p>This option (also called “Configuration Payload” or “Mode CP”) lets the VPN Client get all the information required for the VPN connection from the gateway: VPN Client addresses, remote network address, subnet mask and DNS addresses.</p> <p>When this option is checked, all corresponding fields are disabled (uneditable). They are filled in dynamically as the tunnel is opened with the values sent by the VPN gateway during the Mode CP exchange.</p> <div data-bbox="547 880 595 925" style="background-color: #e1eef6; padding: 10px; margin: 10px 0;"> <p> Mode CP allows the gateway to configure up to 8 subnetworks. In this case, only the first subnetwork must be entered in the “Traffic Selectors” part. All the subnetworks configured by the gateway must be entered in the Console.</p> </div> <div data-bbox="547 1055 595 1099" style="background-color: #e1eef6; padding: 10px; margin: 10px 0;"> <p> If more than 8 subnetworks are configured in the gateway, only the 8 first ones will be taken into account.</p> </div>

Cryptography

Encryption	Encryption algorithm negotiated during the IPsec phase (1): Auto (2), AES CBC (128, 192, 256), AES CTR (128, 192, 256), AES GCM (128, 192, 256).
Integrity	Authentication algorithm negotiated during the IPsec phase (1): Auto (2), SHA2 256, SHA2 384, SHA2 512.
Diffie-Hellman	Length of Diffie-Hellman key (1): Auto (2), DH14 (MODP 2048), DH15 (MODP 3072), DH16 (MODP 4096), DH17 (MODP 6144), DH18 (MODP 8192), DH19 (ECP 256), DH20 (ECP 384), DH21 (ECP 521), No Diffie-Hellman.
Extended Sequence Number	Allows you to use 64-bit extended sequence numbers (see RFC 4304): Auto (2), No, Yes. We recommend using this mode.

(1) Refer to chapter 24 Security recommendations on the choice of algorithm.

(2) Auto means that the VPN Client automatically adapts to the gateway parameters.

Lifetime

Child SA Lifetime

Time interval, expressed in seconds, between two renegotiations.
The default value for the Child SA lifetime is 1800 s (30 min).



As opposed to IKEv1, in IKEv2 lifetimes are not negotiated between the VPN Client and the gateway. This means that the lifetime of the tunnel will be exactly the lifetime configured in VPN Client.

IPv4 / IPv6

IPv4 / IPv6



Refer to chapter 16 IPv4 and IPv6.

Configuring the address type

If the endpoint of the tunnel is a network, choose the “Subnet address” type and then enter the Remote LAN address and Subnet mask:

Address type	Subnet address
Remote LAN address	192 . 168 . 175 . 0
Subnet mask	255 . 255 . 255 . 0

As an alternative, you can also select “Range address” and enter the Start and End addresses:

Address type	Range address
Start address	192 . 168 . 175 . 1
End address	192 . 168 . 175 . 10

If the endpoint of the tunnel is a workstation, choose the “Single address” type and then enter the Remote host address:

Address type	Single address
Remote host address	192 . 168 . 175 . 1



The function “[Automatically open this tunnel on traffic detection](#)” is used to automatically open a tunnel when traffic with one of the addresses specified in the address range is detected (provided that this address range is authorized in the VPN gateway configuration).



If the IP address of the VPN Client workstation is included in the address range for a remote network (e.g. @workstation IP=192.168.10.2 and @remote network=192.168.10.x), then opening a tunnel will prevent the workstation from communicating on the local network. All communications will go through the VPN tunnel.



“All traffic through the VPN tunnel” configuration

The VPN Client can be configured so that all the workstation's outbound traffic goes through the VPN tunnel. To implement this function, select “Subnet address” as the address type and specify “0.0.0.0” as the Remote LAN address and Subnet mask.



Several VPN Client configuration guides for various VPN firewalls/gateways are available on our website at: <https://www.thegreenbow.com/en/support/integration-guides/compatible-vpn-routers/>.

12.4.7 Child SA: Advanced

Alternate servers

DNS Suffix	Domain suffix to be added to all machine names, e.g. "mozart.dev.thegreenbow". This is an optional parameter: When it is specified, the VPN Client will try to translate the machine address without adding the DNS suffix. However, if translation fails, the DNS suffix will be added and the Client will try to translate the address again.
Alternate servers	Table containing the IP addresses of the DNS (maximum 2) and WINS (maximum 2) servers available on the remote network. The IP addresses will be IPv4 or IPv6 addresses depending on the network type configured in the "Child SA" tab.



When Mode CP is enabled (see the "Request configuration from the gateway" parameter in the "Child SA" tab), these fields will be grayed out (uneditable). They are automatically filled in as the tunnel is opened with the values sent by the VPN gateway during the Mode CP exchange.

Tunnel traffic check


Traffic check after opening	<p>The VPN Client can be configured so that connectivity to the remote network is checked on a regular basis. If connectivity has been lost, the VPN Client will automatically close the tunnel and attempt to open it again.</p> <p>The IPv4/IPv6 field is the address of a machine within the remote network, which should reply to pings sent by VPN Client. If a ping goes unanswered, the connection is considered lost.</p>
-----------------------------	---



If the tunnel is configured in IPv4 (see the button at the top right of the tab), then the IPv4 field is displayed. If the tunnel is configured in IPv6, then the IPv6 field is displayed.

Check interval	The "Check interval" indicates the time interval in seconds between two pings sent by the VPN Client to the machine with the IP address specified above.
----------------	--

Miscellaneous

Disable Split Tunneling	When this option is selected, only the traffic going through the tunnel is authorized.  See note (1) below.
-------------------------	---

(1) The "Disable Split Tunneling" configuration option increases the "leakproofness" of the workstation, provided that the VPN tunnel is open. More specifically, this function eliminates the risk of incoming data flows that do not go through the VPN tunnel.

Combined with the "All traffic through the VPN tunnel" configuration (see section 12.4.6 Child SA: Child SA), this option guarantees the complete leakproofness of the workstation, provided that the VPN tunnel is open.

We recommend using this mode.

12.4.8 Child SA: Automation

 Refer to chapter 14 Automation.

12.4.9 Child SA: Remote sharing

 Refer to chapter 18 Remote Desktop Sharing.

12.5 Configuring an SSL VPN tunnel

12.5.1 Introduction

Versions 6 and later of the Windows Standard VPN Client can be used to open SSL VPN tunnels.

SSL VPN tunnels established by the Windows Standard VPN Client are compatible with OpenVPN and can establish secure connections with all gateways that implement this protocol.

12.5.2 SSL: Authentication


Remote Gateway

Interface Name of the network interface on which the VPN connection is open. You can let the software automatically decide which interface to use by selecting “Any”.

We recommend choosing this option if the tunnel being configured is to be deployed on a different workstation.

Remote Gateway IP (IPv4 or IPv6) or DNS address of the remote VPN gateway. This field is mandatory.

Authentication

Select Certificate Choose a certificate for VPN connection authentication.
 Refer to the dedicated chapter: 17 Managing certificates.

Extra Authentication

Extra authentication This option increases the security level by asking the user to enter a login name and password whenever a tunnel is opened.

When the box “Popup when tunnel opens” is checked, users will be prompted for their login name and password whenever they open the tunnel. When it is unchecked, the login name and password must be entered here permanently. Users therefore will not need to enter them every time they open the tunnel.

12.5.3 SSL: Security

The screenshot shows the 'Security' tab of the VPN client configuration. It is divided into three sections:

- Initial Authentication (TLS):** Contains a 'Security Suite' dropdown menu currently set to 'Auto'.
- Traffic Security Suite:** Contains three dropdown menus: 'Authentication' (Auto), 'Encryption' (Auto), and 'Compression' (Auto).
- Extra HMAC (TLS-Auth):** Contains an information icon, an 'Enabled' checkbox (which is unchecked), and a 'Key Direction' dropdown menu.

Initial Authentication (TLS)

Security Suite

This parameter is used to configure the security level of the authentication phase during the SSL exchange.

- Auto: All cryptography suites (except null) are sent to the gateway, which will use the best fit.
- Low: Only weak cryptography suites are sent to the gateway. In the current version, these are suites that use 64 or 56-bit encryption algorithms.
- Normal: Only “medium” cryptography suites are sent to the gateway. In the current version, these are suites that use 128-bit encryption algorithms.
- High: Only strong cryptography suites are sent to the gateway. In the current version, these are suites that use 128-bit or higher encryption algorithms.

For further information: <https://www.openssl.org/docs/man1.1.1/man1/ciphers.html>

Traffic Security Suite

Authentication

Authentication algorithm negotiated for traffic:
Auto (1), MD5, SHA-1, SHA2-256, SHA2-384, SHA2-512.



If the “Extra HMAC” option is enabled (see below), the authentication algorithm cannot be set to “Auto”. It will have to be configured explicitly and must be identical to the one chosen at the gateway end.

Encryption

Traffic encryption algorithm:
Auto (1), BF-CBC-128, AES-128-CBC, AES-192-CBC, AES-256-CBC.

Compression

Traffic compression: Auto (1), Lz0, No, Lz4.

(1) Auto means that the VPN Client automatically adapts to the gateway parameters.

Extra HMAC (TLS-Auth)

Extra HMAC

This option adds an authentication layer to the packets exchanged between the VPN Client and the VPN gateway. For this option to be fully operational, it must also be configured on the gateway (on gateways, this option is often referred to as “TLS-Auth”).

If this option is enabled, a key must be entered in the field below the checked box. The same key must also be entered on the gateway. It consists of a string of hexadecimal characters, in the following format:

```
-----BEGIN Static key-----
362722d4fbff4075853fbe6991689c36
b371f99aa7df0852ec70352122aee7be
...
515354236503e382937d1b59618e5a4a
cb488b5dd8ce9733055a3bdc17fb3d2d
-----END Static key-----
```

The “Key Direction” must also be defined:

- BiDir: The specified key is used in both directions (default mode)
- Client: The key direction must be defined as “Server” on the gateway
- Server: The key direction must be defined as “Client” on the gateway

12.5.4 SSL: Gateway

The screenshot shows the 'Gateway' tab of the VPN Client configuration. It is divided into several sections:

- Dead Peer Detection (DPD):**
 - Ping Gateway (s): 0
 - Detect Gateway (s): 0
 - On Dead Peer Detection: Radio buttons for 'Close tunnel' and 'Re-open tunnel'.
- Gateway related parameters:**
 - Explicit Exit:
 - Check Gateway Certificate: Yes (dropdown)
 - Check Gateway Options: Apply (dropdown)
 - Validate the subject of the gateway certificate: [Empty text box]
 - Redundant Gateway: [Empty text box]
- Miscellaneous:**
 - Disable Split Tunneling:

Dead Peer Detection (DPD)

The Dead Peer Detection (DPD) function enables both endpoints of the tunnel to mutually make sure the other one is active. (1)


Ping Gateway (s)

Period, expressed in seconds, between two pings sent by the VPN Client to the gateway. Sending this ping enables the gateway to determine whether the VPN Client is still active.

Detect Gateway (s)	Time, expressed in seconds, after which the gateway is considered down if no ping has been received.
On Dead Peer Detection	When the gateway is detected as unavailable (i.e. once the "Detect Gateway" time has expired), the tunnel can be closed or the VPN Client may try to open it again.

(1) The DPD function is enabled once the tunnel is open. When linked to a redundant gateway, DPD allows the VPN Client to automatically switch between gateways when one of them is unavailable.

Gateway-related parameters

Explicit exit	This parameter configures the VPN Client to send a specific VPN tunnel closing frame to the gateway when closing the tunnel. If this option is not selected, the gateway will use DPD to close the tunnel at its end, which is less effective.
Check Gateway Certificate	Specifies the control level applied to the gateway's certificate. In the current version, two levels are available: <ul style="list-style-type: none"> - Yes (the validity of the certificate is checked) - No (the validity of the certificate is not checked) The "Lite" option is reserved for future use and, in the current version, it is equivalent to "Yes". If the "Check gateway certificate signature" option is enabled in the PKI Options (cf. section 24.4 PKI options), the present option on the "Gateway" tab is grayed out and the option is set to "Yes".
Check Gateway Options	Used to determine the level of consistency between the VPN tunnel and gateway parameters (encryption algorithms, compression, etc.). <ul style="list-style-type: none"> - Yes: Consistency is checked for all VPN parameters. The VPN tunnel will not open if any parameter is different. - No: Consistency is not checked before opening the tunnel. The VPN tunnel will try to open, even though no traffic may pass through because certain parameters are not consistent. - Lite: Consistency between the VPN Client and the gateway is only checked for essential parameters. - Apply: Gateway parameters will be applied.
Validate the subject of the gateway certificate	If this field is filled in, the VPN Client will check that the subject of the certificate received from the gateway is, indeed, the one specified.
Redundant gateway	Defines the address of a spare VPN gateway that the VPN Client will switch to when the initial gateway is unavailable or unreachable. The address of the redundant VPN gateway can be either an IP or a DNS address.  Refer to chapter 13 Redundant gateway.

Miscellaneous

Disable Split Tunneling	When this option is selected, only the traffic going through the tunnel is authorized. The "Disable Split Tunneling" configuration option increases the "leakproofness" of the workstation, provided that the VPN tunnel is open. More specifically, this function eliminates the risk of incoming data flows that do not go through the VPN tunnel.
-------------------------	--

12.5.5 SSL: Establishment

The screenshot shows the 'Establishment' tab of the VPN configuration window. It contains the following settings:

- Key Renegotiation:** Bytes (KB) = 0, Packets = 0, Lifetime (sec) = 3600.
- Tunnel Options:** Physic.If MTU = 0, Tunnel MTU = 0, Tunnel IPV4 = Auto, Tunnel IPV6 = Auto.
- Tunnel Establishment Options:** Port = 1194, TCP, Authentication timeout = 15, Retransmissions = 2, Traffic setup timeout = 10.
- Traffic:**
 - Traffic detection to open tunnel:** IPV4 and IPV6 fields with slashes between them.
 - Tunnel traffic check:** IPV4 and IPV6 fields.

Key Renegotiation

Bytes (KB), Packets, Lifetime (sec)

Keys can be renegotiated when any of the three criteria (which can be combined) expire:

- Traffic volume, expressed in KB
- Quantity of packets, expressed in number of packets
- Lifetime, expressed in seconds

If more than one criterion is set, keys will be renegotiated when the first of these expires.

Tunnel Options

Physical interface MTU

Maximum size of OpenVPN packets.

Used to set a packet size so that OpenVPN frames are not fragmented at the network level.



The default value for MTU is 0, meaning that the software will use the MTU value of the physical interface.

Tunnel MTU

Virtual interface MTU.

When values have been entered, we recommend setting a lower value for the tunnel MTU than that of the physical interface MTU.

By default, the MTU is set to 0, meaning that the software will use the MTU value of the physical interface.

Tunnel IPv4	<p>Defines the VPN Client's behavior when it receives an IPv4 configuration from the gateway:</p> <ul style="list-style-type: none">- Auto: Accepts the information sent by the gateway- Yes: Checks whether the information sent by the gateway matches the configured behavior. If this is not the case, a warning message is displayed on the console and the tunnel is not established.- No: Ignore <p> Please make sure that the "Tunnel IPv4" and "Tunnel IPv6" options are not both set to "No".</p>
Tunnel IPv6	<p>Defines the VPN Client's behavior when it receives an IPv6 configuration from the gateway:</p> <ul style="list-style-type: none">- Auto: Accepts the information sent by the gateway- Yes: Checks whether the information sent by the gateway matches the configured behavior. If this is not the case, a warning message is displayed on the console and the tunnel is not established.- No: Ignore <p> Please make sure that the "Tunnel IPv4" and "Tunnel IPv6" options are not both set to "No".</p>

Tunnel Establishment Options

Port/TCP	Port number used to establish the tunnel. The default port value is set to 1194. The tunnel will use UDP by default. The "TCP" option is used to transport the tunnel over TCP.
Authentication timeout	Time allowed to establish the authentication phase. When this time expires, it is assumed that the tunnel will not open. When this timeout expires, the tunnel is closed.
Retransmissions	Number of retries for sending a protocol message. If there is no response by the time the defined number of retries is reached, the tunnel is closed.
Traffic setup timeout	Tunnel establishment phase: time after which the tunnel is closed, if not all of the steps have been completed.

Traffic

Traffic detection to open the tunnel

With OpenVPN, the remote network's details are not configured (they are automatically obtained during the tunnel opening exchange with the gateway). To implement traffic detection with OpenVPN, the remote network's details must therefore be stated explicitly. That is the purpose of the IPv4 and IPv6 fields.

It is not mandatory to fill in both fields.

The IP field is a sub-network address, configured as an IP address and a prefix length.

Example: IP = 192.168.1.0 / 24: the first 24 bits of the IP address are taken into account, i.e. the network: 192.168.1.x



These parameters are linked to the traffic detection function. The "Automatically open this tunnel on traffic detection" box must be checked on the "[Automation](#)" tab for the IPv4 and IPv6 fields to be enabled.

Tunnel traffic check

If these fields are filled in, the VPN Client will try to ping these addresses after opening the VPN tunnel. The connection status (reply to pings or no reply to pings) is shown in the console.

It is not mandatory to fill in both fields.



No particular steps are taken if the ping goes unanswered.

12.5.6 SSL: Automation



Refer to chapter 14 Automation.

12.5.7 SSL: Certificate



Refer to chapter 17 Managing certificates.

12.5.8 SSL: Remote sharing



Refer to chapter 18 Remote Desktop Sharing.

13 Redundant gateway

The Windows Standard VPN Client can be used to manage a redundant VPN gateway.

When combined with Dead Peer Detection (DPD) settings, this function allows the VPN Client to automatically switch to the redundant gateway as soon as the main gateway is detected as being down or unavailable.

If the DPD is lost and a redundant gateway has been configured, the tunnel will automatically try to open again. You can configure a redundant gateway that is identical to the main one, in order to benefit from the automatic reopening mode without actually having to use two gateways.

The algorithm for taking into account the redundant gateway is as follows:

The VPN Client contacts the initial gateway to open the VPN tunnel.
If the tunnel cannot be opened after N attempts,
the VPN Client contacts the redundant gateway.

The same algorithm applies to the redundant gateway:

If the redundant gateway is unavailable,
the VPN Client will try to open the VPN tunnel with the initial gateway.



The VPN Client will not try to contact the redundant gateway if the initial gateway can be reached, but issues are experienced when opening the tunnel.



The VPN Client will not try to contact the redundant gateway if the initial gateway cannot be reached due to a DNS resolution issue.

14 Automation

The Windows Standard VPN Client can perform automated actions for each VPN tunnel, such as switching to a fallback tunnel, opening the tunnel automatically if certain criteria are met, running batches or scripts at various stages while opening or closing a tunnel, etc.

These automated actions can be performed on any type of tunnel: IKEv1, IKEv2 and SSL.

These automated actions are configured for each tunnel type on the “Automation” tab of the corresponding tunnel: Phase 2 (IKEv1), Child SA (IKEv2) or TLS (SSL).

The screenshot shows the 'Automation' tab of the Windows Standard VPN Client configuration window. The window has several tabs: Authentication, Security, Gateway, Establishment, Automation (selected), Certificate, and Remote Sharing. The 'Automation' tab is divided into several sections:

- Tunnel fallback:**
 - Tunnel to switch to: None (dropdown menu)
 - Message to display: (text input field)
 - Fallback retries: 0 (text input field)
 - Allow the user to refuse the fallback.
- Automatic Open mode:**
 - Automatically open this tunnel when VPN Client starts after logon.
 - Automatically open this tunnel when USB stick is inserted.
 - Automatically open this tunnel on traffic detection.
- Gina mode:**
 - Enable before Windows logon.
 - Automatically open this tunnel when Gina starts at logon.
- Scripts:**
 - Run this script :
 - Before tunnel opens: (text input field) [Browse...]
 - When tunnel is opened: (text input field) [Browse...]
 - Before tunnel closes: (text input field) [Browse...]
 - After tunnel is closed: (text input field) [Browse...]

Tunnel fallback



Refer to chapter 15 Fallback tunnel.

Automatic Open mode

Automatically open this tunnel when VPN Client starts after logon.

The tunnel will automatically open when the VPN Client is started.

Automatically open this tunnel when USB stick is inserted.

If the tunnel is part of a configuration on a USB drive (refer to chapter 20 USB mode), it will automatically be opened when the USB drive is inserted.

If the tunnel is configured with a certificate stored on a smart card or token, it will automatically be opened when the smart card or token is inserted.

Automatically open this tunnel on traffic detection.	The tunnel will automatically open when traffic is detected that is heading towards an IP address on the remote network.
--	--

GINA mode

Enable before Windows logon	This option specifies that the VPN connection can be opened before the Windows logon: It appears in the GINA connections window (refer to chapter 21 GINA mode below).
Automatically open this tunnel when GINA starts at logon	When this option is enabled, the tunnel will automatically open before the Windows logon. This option is enabled if the option "Enable before Windows logon" is selected.

Scripts

Before tunnel opens	The specified command line is executed before the tunnel opens.
When tunnel is opened	The specified command line is executed as soon as the tunnel is open.
Before tunnel closes	The specified command line is executed before the tunnel closes.
After tunnel is closed	The specified command line is executed as soon as the tunnel is closed.

The command lines can be as follows:

- Calling a "batch" file, e.g. `C:\vpn\batch\script.bat`
- Running a program, e.g. `C:\Windows\notepad.exe`
- Opening a web page, e.g. `https://my.site`
- etc.

There are many possible applications, such as the following:


- Creating a semaphore file when the tunnel is open, so that a third-party application can detect the instant when the tunnel is open
- Opening one of the company's intranet servers automatically once the tunnel is open
- Cleaning or checking a configuration before opening the tunnel
- Checking the workstation (antivirus is up-to-date, correct versions of applications, etc.) before opening the tunnel
- Automatic cleaning (file deletion) of a workspace on the workstation before closing the tunnel
- Application for counting openings, closings, and durations of VPN tunnels
- Changing the network configuration, once the tunnel has been opened, then restoring the initial network configuration once the tunnel has been closed
- etc.



Scripts cannot be configured for a tunnel configured in GINA mode. Data entry fields are disabled.

15 Fallback tunnel

The Windows Standard VPN Client is equipped with a fallback tunnel function, which automatically attempts to open a second tunnel if the first one cannot be opened.



This function can be configured on the “Automation” tab of each tunnel (IKEv1, IKEv2 or SSL).

Tunnel fallback

Tunnel to switch to

Message to display

Fallback retries

Allow the user to refuse the fallback.

Tunnel to switch to	This field displays the list of tunnels to which the software can automatically switch if the current tunnel is unavailable.
Message to display	As this function can automatically switch from one tunnel to another, with the second being, for example, less secure than the first, this option is used to display a warning message to the user. This message will be displayed every time the connection switches to the fallback tunnel.
Max. number of retries	The number of fallback attempts is set in order to avoid infinite switching loops (tunnel 1 falling back to tunnel 2 falling back in turn to tunnel 1).
Allow the user to refuse the fallback	Used to configure the fallback function so that the user gets to decide whether to fall back from one tunnel to another.

16 IPv4 and IPv6

The Windows Standard VPN Client is compatible with IPv4 and IPv6 protocols, both for communicating with the gateway and with the remote network. The VPN Client allows you to combine the use of IPv4 and IPv6, for example to open a secure IPv4 connection in a VPN tunnel transported over IPv6.

The choice between IPv4 and IPv6 is made either based on the IP address if it is digital or based on the DNS resolution. In the latter case, the resolution of the gateway name will provide an IPv4 or IPv6 IP address, or both. If both are provided, preference is given to the IPv4 address.

For IKEv1 and IKEv2 VPN tunnels, the IPv4 or IPv6 protocol configuration can be accessed in the top-right corner of the IPsec (for Phases 2 of IKEv1 tunnels) or Child SA (for Child SA of IKEv2 tunnels) tab.

The IP protocol configured using the IPv4/IPv6 button is exactly the same as the protocol used on the remote network.

The image displays two side-by-side screenshots of the Windows Standard VPN Client configuration interface, specifically the 'Child SA' tab. Both screenshots show the 'Traffic selectors' section with the following fields:

- VPN Client address:** 0 . 0 . 0 . 0 (left) and :: (right)
- Address type:** Subnet address (both)
- Remote LAN address:** 0 . 0 . 0 . 0 (left) and :: (right)
- Subnet mask:** 0 . 0 . 0 . 0 (left) and **Prefix length:** 0 (right)

The top-right corner of each screenshot shows a button for selecting the protocol: 'IPv4' is selected in the left screenshot, and 'IPv6' is selected in the right screenshot.



Choosing between IPv4 and IPv6 has an impact on the settings of the tunnel's other configuration tabs. The IPv4/IPv6 selection button therefore still is shown on the top-right corner of these other tabs, but it is disabled.

For SSL tunnels, the protocol configuration is detected automatically. No configuration is required. Moreover, an SSL tunnel can manage IPv4 and IPv6 traffic simultaneously inside the same tunnel. Unlike for IKEv1 or IKEv2, it is not necessary to configure two separate tunnels.

17 Managing certificates



The Windows Standard VPN Client includes an unparalleled selection of interfacing functions with all types of certificates, issued by any PKI, and on any type of storage device, such as token, smart card, certificate store, etc.

More specifically, the Windows Standard VPN Client implements the following functions and features:

- Use of any type of certificates storage medium: smart card, token, certificate store, file, VPN configuration, USB drive
- PKCS#11, CSP (IKEv1 only), and CNG access to tokens and smart cards
- Support for X.509 certificate formats: PKCS#12, PEM, PFX
- Management of certificates on user's side (the VPN Client's side), such as VPN gateway certificates, including validity dates, certificate chains, root certificates, and CRL management
- Certificate authority (CA) management
- Validation of client and gateway certificates: mutual authentication with identical or different certificate authorities (import specific CAs)

The Windows Standard VPN Client provides additional security features for PKI management, such as automatically opening or closing a tunnel upon insertion or removal of a smart card or token.

The list of smart card readers and tokens compatible with the Windows Standard VPN Client is available on our website at: <https://www.thegreenbow.com/en/support/integration-guides/compatible-vpn-tokens/>.

The certificates to be used are configured and specified in the "Certificate" tab of the relevant tunnel: Phase 1 (IKEv1), IKE Auth (IKEv2) or TLS (SSL).

The following certificate types are supported:

- RSASSA-PKCS1-v1.5 with SHA-2
- RSASSA-PSS with SHA-2
- ECDSA "secp256r1" with SHA-2
- ECDSA "BrainpoolP256r1" with SHA-2
- ECSDSA "secp256r1" with SHA-2
- ECSDSA "BrainpoolP256r1" with SHA-2

17.1 Selecting a certificate ("Certificate" tab)

The Windows Standard VPN Client can assign a user certificate to a VPN tunnel. There can only be one certificate per tunnel, but each tunnel can have its own certificate.

The Windows Standard VPN Client allows you to choose a stored certificate:

- In the VPN configuration file (see below “Importing a certificate”)
- In the Windows Certificate Store (see below “Windows Certificate Store”)
- On a smart card or token (see below “Using a certificate stored on a smart card or token”)

The “Certificate” tab for the relevant tunnel lists all accessible storage media that contain certificates.

- The smart card or token is compatible with CNG, CSP (IKEv1 only), or PKCS#11
- The smart card or token middleware is correctly installed on the computer
- Where appropriate, the smart card is correctly inserted into the corresponding reader

If a medium does not contain any certificates, it simply will not appear in the list (e.g. if the VPN configuration file does not contain any certificates, it will not appear in the list).

Clicking the desired medium displays the list of certificates it contains.

Click the desired certificate to assign it to the VPN tunnel.

You can also click “Automatic selection”. In this case, the VPN Client will automatically select a certificate in the Windows Certificate Store or on the token/smart card reader when it needs it.


For smart cards readers, the reader is displayed with a warning icon in front, if the smart card is not inserted.




Windows Personal Certificate Store
 ACS CCID USB Reader 0



Only available certificates that have not expired are displayed.



Once a certificate has been selected, the “View Certificate” button will show detailed information about the certificate.



Once a certificate has been selected, the tunnel's Local ID type will automatically switch to “X509 subject” or “DER ASN1 DN” and the certificate's subject will be used as the default value of this Local ID.

Identity

Local ID: Subject from X509 C = FR, ST = IDF, L = Paris, O = TGI

Remote ID: []

17.2 Selecting the certificate automatically

On the “Certificate” tab of the relevant tunnel, you can choose the “Automatic selection” button for certificates stored in the Windows Certificate Store or on a token/smart card. In this case, the VPN Client will automatically select the first certificate found on the respective medium.

17.3 Importing a certificate

The Windows Standard VPN Client can import certificates in PEM or PKCS12 format to the VPN configuration. This solution is less secure than using the Windows Certificate Store, a smart card, or a token, but it makes it easier to transport certificates.

This solution has the advantage of combining the certificate (user-specific) and the VPN configuration (generic) in a single file, which can easily be sent to the user's workstation and imported into the VPN Client.

Nevertheless, the disadvantage of transporting certificates in a VPN configuration is that each configuration then becomes user-specific. We therefore do not recommend this solution for a substantial deployment.



Whenever you import a certificate into a VPN configuration, we strongly recommend that you protect the configuration file with a password when you export it (see section 11.2 Exporting a VPN configuration) so that the certificate does not become visible in clear text.

Importing a PEM certificate

- 1/ On the Certificate tab of a Phase 2, click "Import Certificate...".
- 2/ Choose "PEM Format".
- 3/ Click "Browse" to select the root and user certificates as well as the user's private key to import.
- 4/ Click "OK" to confirm.

The certificate is shown and is selected in the certificate list displayed on the "Certificate" tab.
Save the VPN configuration: The certificate will be saved in the VPN configuration.

Importing a PKCS#12 certificate

- 1/ On the Certificate tab of a Phase 2, click "Import Certificate...".
- 2/ Choose "P12 Format".
- 3/ Click "Browse" to select the PKCS12 certificate to import.
- 4/ If it is password-protected, enter the password and then click "OK" to confirm.



The file containing the private key may not be encrypted.

The certificate is shown and is selected in the certificate list displayed on the "Certificate" tab.

Save the VPN configuration: The certificate will be saved in the VPN configuration.

17.4 Windows Certificate Store

For the Windows Standard VPN Client to identify a certificate available in the Windows Certificate Store, it must meet the following criteria:

- The certificate must be certified by a certificate authority (which excludes self-signed certificates)
- The certificate must be located in the "Personal" Certificate Store (it represents the personal identity of the user who wants to open a VPN tunnel to the corporate network)



Microsoft provides a standard management tool (certmgr.msc) to manage the certificates in the Windows Certificate Store. To run this tool, go to the Windows "Start" menu and then enter "certmgr.msc" in the "Search for programs or files" field.

17.5 VPN gateway certificate

We recommend forcing the Windows Standard VPN Client to check the certificate chain of the certificate received from the VPN gateway (default behavior).



Refer to the paragraph entitled [Checking certificates](#) in section 22.4 PKI options.

To do this, you need to import the root certificate and all certificates in the certificate chain (root certificate authority and intermediate certificate authorities) to the configuration file or to the Windows Certificate Store.

Checking each item in the chain implies that the following are checked:

- Gateway certificate expiration date
- Certificate validity start date
- Signatures of all certificates in the certificate chain (including root certificate, intermediate certificates and server certificate)



The Windows Standard VPN Client does not check the Certification Revocation List (CRL).

17.6 Managing certificate authorities

If the Windows Standard VPN Client is configured to check gateway certificates, the Certificate Authorities (CAs) must also be accessible.

You must import the gateway's root CA into the configuration.

If the gateway is not configured to send CAs, you must also import the intermediate CAs into the configuration.

The following intermediate CA types are supported:


- RSASSA-PKCS1-v1.5 with SHA-2
- RSASSA-PSS with SHA-2
- ECDSA "secp256r1" with SHA-2
- ECDSA "BrainpoolP256r1" with SHA-2
- ECSDSA "secp256r1" with SHA-2
- ECSDSA "BrainpoolP256r1" with SHA-2

The following root CA types are supported:

- RSASSA-PKCS1-v1.5 with SHA-1
- RSASSA-PSS with SHA-1
- RSASSA-PKCS1-v1.5 with SHA-2
- RSASSA-PSS with SHA-2
- ECDSA "secp256r1" with SHA-2
- ECDSA "BrainpoolP256r1" with SHA-2
- ECSDSA "secp256r1" with SHA-2
- ECSDSA "BrainpoolP256r1" with SHA-2



In the current version of the Windows Standard VPN Client, you cannot add more than three CAs to a configuration.



- 1/ In the "Certificate Authority Management" window, click "Add CA".
- 2/ Choose the desired CA certificate type (PEM or DER).
- 3/ Click "Browse" to select the CA to import.



As of version 6.8 of the Windows Standard VPN Client, for security reasons, the Windows Certificate Store can no longer be used to access CAs.

17.7 Using a certificate stored on a smart card or token

When a VPN tunnel is configured to use a certificate stored on a smart card or token, users will be prompted for the PIN code required to access this smart card or token every time a tunnel is opened.

If the smart card is not inserted or the token cannot be accessed, the tunnel will not open.

If an incorrect PIN code is entered, the Windows Standard VPN Client will show a warning, informing users that they only have three (in most cases) consecutive attempts to unlock the smart card or token.

The Windows Standard VPN Client implements a mechanism to automatically detect smart card insertion.


Tunnels that are associated with a certificate stored on a smart card will therefore be established automatically when the smart card is inserted. Likewise, removing the smart card will close all the corresponding tunnels.

To implement this function, check “Automatically open this tunnel when a USB stick is inserted” (see section 14 Automation).

18 Remote Desktop Sharing

Opening a Remote Desktop session on a Windows computer over the internet usually requires that you establish a secure connection and enter the connection parameters (address of the remote computer, etc.).

The Windows Standard VPN Client allows you to simplify and automatically secure the opening of a Remote Desktop session: The VPN connection to the remote workstation is established and the Remote Desktop Protocol (RDP) session automatically opens on this remote workstation with a single click.



To set up Remote Desktop Sharing, proceed as follows:

- 1/ Select the VPN tunnel (Phase 2, Child SA, or TLS) in which the Remote Desktop session will be opened.
- 2/ Select the "Remote Sharing" tab.
- 3/ Enter an alias for the connection (the name will be used to identify the connection in the various software menus), then enter the IP address or the Windows name of the remote workstation.
- 4/ Click "Add". The Remote Desktop Sharing (RDP) session will be added to the list of sessions.

Child SA Advanced Automation Remote Sharing IPV4 IPV6

Enter below the IP address of the remote computer you want to connect to, and choose an alias.

Alias

Computer name or IP address

Alias	Name or IP address

Child SA Advanced Automation Remote Sharing IPV4 IPV6

Enter below the IP address of the remote computer you want to connect to, and choose an alias.

Alias


Computer name or IP address

Alias	Name or IP address
Corporate_desktop	192.168.175.50

To open this RDP connection with a single click, we recommend displaying it specifically in the Connection Panel using the function described in detail in the section entitled "[Managing the Connection Panel](#)" below.


19 Managing the Connection Panel

The Connection Panel of the Windows Standard VPN Client is entirely configurable.



VPN connections can be VPN tunnels or Remote Desktop connections, i.e. a VPN tunnel for which the Remote Desktop function has been specified.

A window that can be accessed from the "Tools > Connections Configuration" menu allows you to manage VPN connections in the Connection Panel, i.e. creating, naming, and sorting them.



The configuration window in the Connection Panel is used for the following actions:

- Choosing the VPN connections that are shown in the Connection Panel
- Creating and sorting VPN connections
- Renaming VPN connections

The left side of the window shows the list of connections as they appear in the Connection Panel.

The right side shows the “General” tab, which specifies the parameters of each connection: its name, the associated VPN tunnel and possibly the Remote Desktop Sharing (RDP) connection, if it has been configured.

To create a new VPN connection, click “Add a new connection”, choose a name and select the corresponding VPN tunnel. If a Remote Desktop Sharing connection is configured, an option used to select it automatically appears below the selected tunnel. Once they have been confirmed, changes made in the Connection Panel configuration window instantly appear in the Connection Panel.




The Connection Panel configuration is stored in the VPN configuration file. Therefore, it can be exported into `.tgb` files, which are useful for deploying an identical Connection Panel across all workstations.

20 USB mode

20.1 Overview

The Windows Standard VPN Client features a unique VPN connection management mode known as the USB mode.


In this mode, the VPN configuration is securely stored on a removable storage device (USB drive). No VPN security elements are stored on the workstation from which the VPN connection is opened. The VPN connection is established automatically as soon as the USB drive is inserted and closed when the USB drive is removed.



Hereinafter, the USB drive containing the VPN configuration will be referred to as "VPN USB drive".

20.2 Configuring the USB mode

The USB mode is configured using the configuration wizard available from the "Configuration > Move to USB Drive" menu of the Configuration Panel.




Step 1: Choosing a USB drive

Screen 1 allows you to choose the removable storage device (USB drive) to use to protect the VPN configuration.


If a drive is already inserted, it is automatically displayed in the list of available USB drives.

Otherwise, simply insert the selected USB drive at this stage. It will be detected automatically as soon as it is inserted.

No USB drive inserted



USB drive already inserted



Step 2: Protecting the VPN configuration in USB mode

The following two protections are available:

1/ Pairing with the user's workstation:

In USB mode, the VPN configuration can be uniquely paired to the workstation from which it originates.

In this case, the VPN USB drive can only be used on this workstation.


On the other hand, if the USB drive is not paired with a specific workstation, the VPN USB drive can be used on any workstation equipped with the Windows Standard VPN Client.

2/ Password protection:


In USB mode, the VPN configuration can be password-protected.

In this case, the password will be required every time the VPN USB drive is inserted.

The USB mode only allows you to protect a single VPN configuration on a USB drive. If there already is a VPN configuration on the inserted USB drive, the following warning will be displayed:




If an empty USB drive is inserted and it is the only drive inserted into the workstation, the wizard will automatically proceed to step 2.




Step 3: Automatically opening the tunnel

The wizard allows you to configure which VPN connections are opened automatically every time the VPN USB drive is inserted.



Step 4: Summary


The summary gives you the opportunity to check whether the VPN USB drive has been properly configured.




Once this final step is confirmed, the workstation's VPN configuration is transferred onto the USB drive. It remains enabled for as long as the USB drive is inserted. When the VPN USB drive is removed, the Windows Standard VPN Client will revert to an empty VPN configuration.

20.3 Using the USB mode

After starting the Windows Standard VPN Client, regardless of whether a VPN configuration is loaded, insert the VPN USB drive. The following information window is automatically displayed:



Once the prompt has been confirmed, the USB mode VPN configuration is automatically loaded and, where appropriate, the corresponding tunnel(s) is (are) opened automatically. A "USB mode" icon is shown in the top-right corner of the tree on the Configuration Panel when the USB mode is enabled:



The VPN connections running in USB mode automatically close when the VPN USB drive is removed. The VPN configuration contained in the USB drive is removed from the workstation. (If a VPN configuration had already been set on the workstation before the USB drive was inserted, it will be restored in the software.)



The Windows Standard VPN Client can only take into account a single VPN USB drive at a time. As long as a VPN USB drive is inserted, any additional VPN USB drives that are inserted will not be taken into account



The import function is disabled in USB mode.

The VPN configuration can be edited in USB mode. Any changes made to the VPN configuration are saved to the VPN USB drive.

The VPN Client does not provide any function to directly change the password or the pairing with a workstation.

In order to change these parameters, follow the steps below:



- 1/ Insert the VPN USB drive.
- 2/ Export the VPN configuration.
- 3/ Remove the VPN USB drive.
- 4/ Import the VPN configuration exported in step 2.
- 5/ Reload the USB mode wizard with this configuration and the desired new parameters.

21 GINA mode

21.1 Overview

The GINA mode allows you to open VPN connections before the Windows logon.

This function can, for example, create a secure connection to an access rights management server so that the user workstation access rights can be obtained before opening a user session.

When a tunnel is configured in GINA mode, a window allowing you to open a tunnel that is similar to the Connection Panel will be displayed on the Windows logon screen. It allows you to open a VPN tunnel manually or automatically.




21.2 Configuring the GINA mode

Configuring the GINA mode for a VPN connection is done on the “Automation” tab of the relevant tunnel.



Refer to chapter 14 Automation.



21.3 Using the GINA mode

When the VPN tunnel is configured in GINA mode, the window used to open GINA tunnels is displayed on the Windows logon screen. The tunnel will open automatically if it is configured accordingly.

A GINA-mode VPN tunnel can perfectly implement an EAP authentication (users must enter their login name and password) or a certificate-based authentication on a token or smart card (users must enter the PIN code required to access the smart card or token).



If two tunnels are configured in GINA mode and one of the two is set to open automatically, it may happen that both tunnels will open automatically.



For the “Automatically open this tunnel on traffic detection” option to be operational after Windows logon, the “Enable before Windows logon” option must not be checked.



Limitation: Scripts and USB mode are not available for VPN tunnels configured in GINA mode.



A VPN tunnel configured with a certificate stored in the Windows User Certificate Store will not work in GINA mode. The reason for this is that the GINA mode is run before a Windows user is identified (prior to opening any session). Therefore, the software cannot identify the user store to use in the Windows Certificate Store.

Security considerations


A tunnel configured in GINA mode can be opened before Windows logon, i.e. by any user of the workstation. We therefore strongly recommend that you set up a strong authentication method that is certificate-based and, if possible, stored on a removable device.

22 Options

22.1 Displaying/hiding the interface


Using the options listed in the “View” tab of the “Options” window, you can hide all the software's interfaces by removing the items “Console”, “Connection Panel” and “Configuration Panel” from the taskbar menu. The taskbar menu can therefore be reduced to the single item “Quit”.

The pop-up window that appears when a tunnel is opened or closed can also be hidden (“Don't show the systray sliding popup” option).




In the Windows Standard VPN Client, the interface of the Configuration Panel is accessible to all users, by default. To restrict access to the Configuration Panel to administrators, check the “Restrict access to Configuration Panel to administrator” option.

To start the VPN Client in administrator mode, right-click the TheGreenBow VPN Client icon and then select the “Run as administrator” menu item.



22.2 General



VPN Client startup mode

If the option “automatically after Windows logon” is checked, the VPN Client will start automatically when the user session is opened.

If the option is not checked, the user must start the VPN Client manually, either by double-clicking on the desktop icon or by selecting the software in the Windows “Start” menu.



Refer to section 6.2 Starting the software.

Disabling detection of network interface disconnection

The standard behavior of the VPN Client is to close the VPN tunnel at its end as soon as a communication issue is encountered on the remote VPN gateway.

For unreliable physical networks prone to frequent micro-disconnections, this function can have drawbacks (which can go as far as not being able to open a VPN tunnel).

By checking the “Disable detection of network interface disconnection” box, the VPN Client won't close tunnels as soon as a disconnection is observed. This ensures greater stability of the VPN tunnel on unreliable physical networks, typically satellite networks.

Show connection popup


A connection window will be displayed automatically every time a VPN connection is established. This feature can be disabled by unchecking the “Show connection popup” box.

22.3 Managing logs

 Refer to section 23.1 Administrator logs.

22.4 PKI options

The “PKI Options” tab provides access to the “Check gateway certificate signature” option.



Checking certificates

Check gateway certificate signature

When this option is selected, the VPN gateway certificate is checked (including its validity date), as well as all certificates in the certificate chain down to the root certificate.




Security advisory: When this option is selected, the subject of the gateway certificate must be entered in the Remote ID of the tunnel concerned to prevent vulnerability [2018_7293](#) from being exploited.

22.5 Managing languages

22.5.1 Choosing a language

The Windows Standard VPN Client can run in several languages. You can change languages while running the software.

To choose another language, open the “Tools > Options” menu, then select the “Language” tab. Choose the desired language in the drop-down menu:



The list of languages available in the standard version of the software is provided in an appendix in section 25.3 Technical data of the Windows Standard VPN Client.


22.5.2 Editing or creating a language

The Windows Standard VPN Client lets you create new translations or edit the language used, then test these changes dynamically using the integrated translation tool.



Any translation sent to TheGreenBow will be checked, published on [TheGreenBow's](#) website, and then included in the software, usually in the official release following receipt of the translation.

In the “Language” tab, click the “Edit language...” link to display the translation window:



The translation window is split into 4 columns, which display the number of the character string, its identifier, its string in the original language and its translation in the selected language respectively.

Using the translation window, you can perform the following actions:

- 1/ Translate each character string by clicking on the corresponding row.
- 2/ Search for a specific character string in any column of the table (use the “Find” field then the “F3” key to browse through every occurrence of the character string you have entered).
- 3/ Save the changes (“Save” button).
Any language you have edited or created is saved in a “.lng” file.
- 4/ Immediately apply changes to the software: this function lets you assess the relevance of any character string and ensure that it is properly displayed in real time (“Apply” button).
- 5/ Send a new translation to TheGreenBow (“Submit” button).

The name of the currently edited language file will appear as a reminder in the header of the translation window.



Any translation sent to TheGreenBow will be checked, published on [TheGreenBow's](#) website, and then included in the software, usually in the official release following receipt of the translation.



The characters or character strings below must not be modified during translation:

- “%s” the software will replace it by a character string
- “%d” the software will replace it by a number
- “\n” indicates a carriage return
- “&” indicates that the following character must be underlined
- “%m-%d-%Y” indicates a date format (in this case US format: month-day-year).
Only edit this field if you are certain of the format used in the target language.

The string “IDS_SC_P11_3” must be left as is.

23 Administrator logs, console and traces

The Windows Standard VPN Client provides three types of logs:


- 1/ “Administrator” logs are specifically designed for software activity and usage reports.
- 2/ The “Console” provides detailed information on the tunnels as well as the related opening and closing steps. It essentially consists of the IKE messages and provides high-level information about the establishment of the VPN tunnel. It is intended for administrators to identify possible VPN connection issues.
- 3/ The “Trace” mode makes every component of the software write an activity log about its inner workings. This mode is intended for TheGreenBow support in order to diagnose software issues.

23.1 Administrator logs

The Windows Standard VPN Client can collect “administrator” logs: tunnel opening, expired certificate, connection duration, wrong login name/password, changes to the VPN configuration, import or export of this configuration, etc. “Administrator” logs provide a first level of analysis for any issues that may be encountered.

Collected logs can be stored in a local file.

Administrator logs are configured in the “Tools > Options...” window on the “Logs management” tab.



Administrator logs are listed in section 25.2 Administrator logs in the appendixes.



When administrator logs are stored in a local file, the path to these logs is the “System” sub-directory in the logging directory: “C:\ProgramData\TheGreenBow\TheGreenBow VPN\LogFiles\System”. Read access to this directory is available in all modes, but write access is only available in Administrator mode.

23.2 Console

Access the Console using either of the following methods:

- “Tools > Console” menu in the Configuration Panel (main interface)
- CTRL+D shortcut when the Configuration Panel is open
- From the software’s taskbar menu, choose “Console”

```
VPN Console ACTIVE
Save Stop Clear Reset IKE
TheGreenBow VPN Client 6.86.007
20210615 19:19:07:031 [VPNCONF] TGBIKE_STARTED received
20210615 19:19:23:042 TIKEV2_TgbTest SEND INFORMATIONAL [HDR] MID=0006
20210615 19:19:23:056 TIKEV2_TgbTest RECV INFORMATIONAL [HDR] MID=0006
20210615 19:19:23:260 TIKEV2_TgbTest SEND INFORMATIONAL [HDR][DELETE]
20210615 19:19:23:260 TIKEV2_TgbTest SEND INFORMATIONAL [HDR][DELETE]
20210615 19:19:23:275 TIKEV2_TgbTest RECV INFORMATIONAL [HDR][DELETE] with old SPI
20210615 19:19:23:275 TIKEV2_TgbTest RECV INFORMATIONAL [HDR] MID=0008 with old SPI
20210615 19:19:23:275 TIKEV2_TgbTest [VirtualItf] Virtual Interface properly deconfigured for inst
20210615 19:19:31:227 Upgrading configuration...
20210615 19:19:31:227 Reading configuration...
20210615 19:19:31:243 IKEv1 configuration detected
20210615 19:19:31:243 Default IKE daemon is removing SAs...
20210615 19:19:31:243 Default reinitializing daemon
20210615 19:19:31:243 TIKEV2_TgbTest configuration OK
20210615 19:19:31:243 No SSL configuration
Current line: 15 Max. lines: 10000
```

The Console has the following functions:

- Save: Saves all the traces displayed in the window into a file
- Start/Stop: Starts/stops a console log
- Clear: Clears the contents of the window
- Reset IKE: Restarts the IKE service

23.3 Trace mode

Trace mode is enabled using the following shortcut: CTRL+ALT+T

You do not need to restart the software when you enable the trace mode.

When the trace mode is enabled, every component of the Windows Standard VPN Client generates activity logs. The logs produced are stored in a folder that you can access by clicking the blue “folder” icon located in the status bar of the Configuration Panel (main interface).



Trace logs can only be enabled on the Configuration Panel and access to the Configuration Panel can be restricted to administrators.



Even though logs do not contain any sensitive information, we recommend that, if enabled by the administrator, said administrator ensures that they are disabled and, if possible, deleted when quitting the software.



Log files are generated every day and kept for 10 days. The software automatically deletes any files that are older than this.



“Administrator” logs that are stored in a local file will not be deleted (see section 23.1 Administrator logs).

24 Security recommendations

24.1 Assumptions

In order to maintain a proper security level, the operating conditions and usages listed below must be observed:

- 1/ The system and network administrator as well as the security administrator, respectively tasked with installing the software and defining the VPN security policies, are nonhostile. They are trained to carry out the tasks for which they are responsible and follow administrative manuals and procedures.
- 2/ The security administrator regularly ensures that the product's configuration is in line with the one that he or she has set up and performs the necessary updates when necessary.
- 3/ Users of the software are nonhostile and have been properly trained on how to use it. More specifically, users execute the tasks for which they are responsible to ensure proper operation of the product and do not reveal the information used for their authentication with the VPN gateway.
- 4/ The user workstation is safe and properly administered. It is equipped with an up-to-date antivirus software and is protected by a firewall.
- 5/ Bi-keys and certificates used to open the VPN tunnel are generated by a trustworthy certificate authority that guarantees compliance with management rules for these cryptographic elements and, more specifically, with the specifications laid out by your local cybersecurity agency, e.g. [\[RGS B1\]](#) and [\[RGS B2\]](#) in France (only available in French).
- 6/ The product's logging function is enabled and properly configured. Administrators are responsible for regularly reviewing the logs.

24.2 User workstation

The machine on which the Windows Standard VPN Client is installed and run must be safe and properly administered. More specifically:

- 1/ Antivirus software must be installed, and its signature database must be updated on a regular basis.
- 2/ It must be protected by a firewall that controls (partitions or filters) the workstation's inbound and outbound communications that do not go through the VPN Client.
- 3/ Its operating system is up to date with the various security patches.
- 4/ Its configuration is such that it is protected against local attacks (memory forensics, patch, or binary corruption).

Configuration recommendations to strengthen the workstation are available on the ANSSI website (in French), such as the following (the list is non-exhaustive):

- [Computer health guide](#) (Guide d'hygiène informatique, document only available in French)
- [Configuration guide](#) (Guide de configuration, document only available in French)
- [Password](#) (Mot de passe, document only available in French)

24.3 VPN Client administration

The Windows Standard VPN Client is designed to be installed and configured with "administrator" privileges and then to be used with "user" privileges only.

We recommend that you protect access to the VPN configuration with a password and restrict the software's visibility to end users (default behavior of the Windows Enterprise VPN Client) as detailed in section 22.1 Displaying/hiding the interface.

The software must therefore be run as administrator to be able to access the Configuration Panel. We recommend keeping the "Start VPN Client after Windows Logon" mode enabled, which is the default mode upon installation.

Lastly, please note that the Windows Standard VPN Client will apply the same VPN configuration to all users of a multiple-user workstation. Consequently, we recommend running the software on a dedicated workstation (for instance by keeping an administrator account and a user account, as mentioned above).

24.4 VPN configuration

24.4.1 Sensitive information in the VPN configuration

We recommend that you do not store any sensitive data in the VPN configuration file.

In this regard, we recommend that you do not use the following features of the software:

- 1/ Do not use the EAP (password/login) mode alone, but only in combination with a certificate.
- 2/ If EAP is used, do not store the EAP login name/password in the VPN configuration (function described in section 12.4.1 IKE Auth: , paragraph entitled [Authentication](#)).
- 3/ Do not import any certificates to the VPN configuration (function described in section 17.3 Importing a certificate) and preferably use certificates stored on removable devices (tokens) or in the Windows Certificate Store.
- 4/ Do not use the "Preshared key" mode (function described in section 12.4.1 IKE Auth: ") and preferably use the "Certificate" mode with certificates stored on removable media (tokens) or in the Windows Certificate Store.
- 5/ Do not export the VPN configuration without encrypting it, i.e. not password-protected (function described in section 11.2 Exporting a VPN configuration).

24.4.2 Authenticating users

The user authentication functions available in the Windows Standard VPN Client are described below, from the weakest to the strongest.

In particular, it should be noted that preshared key authentication, despite being easy to implement, enables any user of the workstation to establish a VPN tunnel without cross-checking their authentication.

Type of user authentication	Strength
Preshared key	Weak
EAP	
EAP popup	
Certificate stored in the VPN configuration	
Certificate in the Windows Certificate Store	
Certificate on a smart card or token	Strong

24.4.3 Authenticating the VPN gateway

We recommend that you implement a check on the VPN gateway certificate as described in section 22.4 PKI options.

24.4.4 Protocol

We recommend that you only configure IKEv2 tunnels.

24.4.5 “All through the tunnel” and “split tunneling” modes

We recommend that you configure the VPN tunnel using the “All traffic through the tunnel” mode and enable the “Disable Split Tunneling” mode.



Refer to the paragraph entitled [Configuring the address type](#) in section 12.4.6 Child SA: Child SA and to the paragraph entitled [Miscellaneous](#) in section 12.4.7 Child SA: Advanced).

24.4.6 GINA mode

We recommended that you choose a strong authentication method for all tunnels configured in GINA mode.

24.4.7 ANSSI recommendations

The recommendations described above can be complemented by French National Cybersecurity Agency's (ANSSI) IPsec configuration document: [Recommendations for securing IPsec networks](#).

25 Appendixes

25.1 Shortcuts

Connection Panel

- ESC Closes the window
- CTRL+ENTER Opens the Configuration Panel (main interface)
- Arrow keys The Up and Down arrow keys are used to select a VPN connection
- CTRL+O Opens the selected VPN connection
- CTRL+W Closes the selected VPN connection

VPN configuration tree

- F2 Used to edit the name of the selected Phase
- DEL Deletes a selected phase, if any, after confirmation by the user
If the actual configuration is selected (root of the tree), the software asks whether a full reset of the configuration should be performed.
- CTRL+O Opens the corresponding VPN tunnel if a Phase 2 is selected
- CTRL+W Closes the corresponding VPN tunnel if a Phase 2 is selected
- CTRL+C Copies the selected phase to the clipboard
- CTRL+V Pastes (adds) the Phase copied to the clipboard
- CTRL+N If the VPN Configuration is selected, creates a new phase 1, or creates a new phase 2 for the selected phase 1
- CTRL+S Saves the VPN configuration

Configuration Panel

- CTRL+ENTER Switches to the Connection Panel
- CTRL+D Opens the "Console" window with VPN traces
- CTRL+ALT+R Restarts the IKE service
- CTRL+ALT+T Enables the trace mode (log generation)
- CTRL+S Saves the VPN configuration

25.2 Administrator logs

ID Log define	ID Log value	Severity	Log string
LOGID_STARTERINIT	1001	Notice	Starter service is started.
LOGID_VPNCONFSTARTING	2001	Notice	GUI is starting.
LOGID_VPNCONFSTOPPED	2002	Notice	GUI has closed.
LOGID_PWDSET	2004	Info	Admin password has been changed.
LOGID_PWDCHECK	2005	Error/Info	Admin password has been verified (status %d).
LOGID_PWDRESET	2006	Warning	Admin password has been reset.
LOGID_TGBIKESTARTED	3001	Notice	IKE has started (status %d).
LOGID_TGBIKESTOPPED	3002	Notice	IKE has stopped.
LOGID_TUNNELOPEN	3004	Info	Tunnel %s is asked to open.
LOGID_VPNCONFCRASHED	2003	Notice	GUI crashed (state %d).
LOGID_TGBIKECRASHED	3003	Notice	IKE crashed (state %d).
LOGID_STARTERSTOP	1002	Notice	Starter service is stopped.
LOGID_RESETIKE	2007	Warning	IKE is asked to reset.
LOGID_VPNCONFSTARTED	2008	Notice	GUI has started from user %s.
LOGID_VPNCONFSTOPPING	2009	Notice	GUI is stopping from user %s.
LOGID_VPNCONFLOADERROR	2010	Error	Configuration couldn't load (reason: %s).
LOGID_VPNCONFOPENTUNNEL	2011	Info	GUI opens tunnel (source: %s).
LOGID_VPNCONFCLOSETUNNEL	2012	Info	GUI closes tunnel (source: %s).
LOGID_VPNCONFSAVE	2013	Notice	New configuration is saved.
LOGID_VPNCONFIMPORT	2014	Info	%s has been imported.
LOGID_VPNCONFIMPORTERR	2015	Error	%s could not be imported (status %d).
LOGID_VPNCONFEXPORT	2016	Info	%s has been exported.
LOGID_TOKENINSERT	2017	Info	Token %s has been inserted.
LOGID_TOKENEXTRACT	2018	Info	Token %s has been extracted.
LOGID_USBINSERT	2019	Info	USB Key has been inserted
LOGID_USBEXTRACT	2020	Info	USB Key has been extracted
LOGID_INSTALLATION	2021	Info	VPN running for the 1st time.
LOGID_UPDATE	2022	Info	VPN software has been updated to version %s.
LOGID_VERSION	2023	Info	VPN Version is %s.
LOGID_GINASTARTED	4001	Notice	GINA has started.
LOGID_GINASTOPPING	4002	Notice	GINA is stopping.
LOGID_GINAOPENTUNNEL	4003	Info	GINA opens tunnel (source: %s).
LOGID_GINACLOSETUNNEL	4004	Info	GINA closes tunnel (source: %s).
LOGID_TUNNELAUTH_OK	3005	Info	Tunnel authentication Ok (%s).
LOGID_TUNNELTRAFFIC_OK	3006	Info	Tunnel %s Ok
LOGID_TUNNELAUTH_NOK	3007	Error	Tunnel authentication failed (reason %d).
LOGID_TUNNELTRAFFIC_NOK	3008	Error	Tunnel %s failed (reason %d).
LOGID_AUTHREKEYING	3009	Info	Tunnel %s initiated rekey (source %d).
LOGID_AUTHREKEYED	3010	Info	Tunnel %s rekeyed.
LOGID_TUNNELREKEYING	3011	Info	Tunnel %s initiated rekey (source %d).
LOGID_TUNNELREKEYED	3012	Info	Tunnel %s rekeyed.
LOGID_PINCODE	3013	Notice/Error	Pin code is entered (status %d).
LOGID_DRIVERNOK	3014	Critical	Driver could not be loaded (status %d).
LOGID_IKEEXT_STOP	1003	Warning	IKEEXT service is stopped.
LOGID_IKEEXT_RESTART	1004	Notice	IKEEXT service is restarted.
LOGID_IKEEXT_ERROR	1005	Critical	IKEEXT could not be stopped (status %d).
SYSTEMLOGID_VIRTIFOK	3015	Info	Virtual interface created successfully (instance %d).
SYSTEMLOGID_VIRTIFNOK	3016	Error	Virtual interface could not be created (error %d).
LOGID_TUNNELCLOSED	3017	Notice	%s tunnel successfully closed (%d min).
LOGID_TUNNELCLOSED_ERR	3018	Error	%s tunnel closed unexpectedly (%d).
LOGID_CERTERROR	3019	Error	Error %d when handling certificate %s.
LOGID_TUNNELDATA_UL	3020	Info	%d bytes sent inside the tunnel.
LOGID_TUNNELDATA_DL	3021	Info	%d bytes received inside the tunnel.

25.3 Technical data of the Windows Standard VPN Client

General

Windows version	Windows 10 & 11, 64-bit
Languages	Arabic, Chinese (simplified), Czech, Danish, Dutch, English, Farsi, Finnish, French, German, Greek, Hindi, Hungarian, Italian, Japanese, Korean, Norwegian, Polish, Portuguese, Russian, Serbian, Slovenian, Spanish, Thai, Turkish

Operating mode

Invisible mode	Automatically open tunnel when traffic is detected Control access to VPN configurations Hide part or all of the interfaces
USB mode	No more VPN configurations stored on the workstation Open tunnel when a USB drive configured for VPN is inserted Automatically close tunnel when a USB drive configured for VPN is removed
Gina	Open a tunnel before Windows logon using: GINA/Credential providers on Windows 10 & 11
Scripts	Run configurable scripts when opening or closing a VPN tunnel
Remote Desktop Sharing	Open a remote computer with a single click via RDP and VPN tunnel

Connection/Tunnel

Connection mode	Peer-to-gateway
Media	Ethernet, DSL, cable, Wi-Fi, 4G, 5G, satellite
Protocols	IPsec IKEv1 or IKEv2 (IKE based on OpenBSD 3.1 (ISAKMPD)) SSL Diffie-Hellman DH group 14 to 21
Tunneling modes	Main mode and Aggressive mode
Mode Config/Mode CP	Automatically retrieve network parameters from VPN gateway

Cryptography

Encryption	<p>Symmetric: AES CBC/CTR/GCM 128/192/256 bits</p> <p>Asymmetric: RSA</p> <p>Diffie-Hellman: DH14 (MODP 2048), DH15 (MODP 3072), DH16 (MODP 4096), DH17 (MODP 6144), DH18 (MODP 8192), DH19 (ECP 256), DH20 (ECP 384), DH21 (ECP 521)</p> <p>Hash: SHA2-256, SHA2-384, SHA2-512</p>
Authentication	<p>Administrator: Protect access to the VPN configurations</p> <p>User:</p> <ul style="list-style-type: none"> - Static or dynamic X-Auth (prompt every time a tunnel is opened) - Hybrid Authentication - Preshared key - EAP (MSCHAP-V2) - Multiple Auth
PKI	<ul style="list-style-type: none"> - Support for certificates in X.509 format: PKCS#12, PEM - Multiple media: Windows Certificate Store, smart card, token, configuration file - Access smart cards and tokens in PKCS#11 or CNG format - Check "Client" and "Gateway" certificates

Miscellaneous

NAT/NAT-Traversal	NAT-Traversal Draft 1 (enhanced), Draft 2, Draft 3 and RFC 3947, IP address emulation, includes support for: NAT_OA, NAT keepalive, NAT-T aggressive mode, NAT-T in forced, automatic or disabled mode
DPD	RFC 3706. Detection of inactive IKE endpoints.
Redundant gateway	Redundant gateway management, automatically selected when DPD is triggered (inactive gateway)

Administrative

Deployment	Installation and updates using Microsoft Installer (MSI)
VPN configuration management	Import and export options for VPN configurations Password-protected import/export and encryption
Logs and traces	IKE/IPsec and SSL/OpenVPN log console and trace mode can be enabled Administrator logs: local file
Updates	Check for available updates from within the software
License and activation	Perpetual license, manual/automatic activation

25.4 Third-party licenses

Credits and references to third-party licenses.

25.4.1 OpenSSL

OpenSSL is licensed under the Apache License 2.0 reproduced below.

Apache License
Version 2.0, January 2004
<https://www.apache.org/licenses/>

TERMS AND CONDITIONS FOR USE, REPRODUCTION, AND DISTRIBUTION

1. Definitions.

"License" shall mean the terms and conditions for use, reproduction, and distribution as defined by Sections 1 through 9 of this document.

"Licensor" shall mean the copyright owner or entity authorized by the copyright owner that is granting the License.

"Legal Entity" shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, "control" means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (ii) ownership of fifty percent (50%) or more of the outstanding shares, or (iii) beneficial ownership of such entity.

"You" (or "Your") shall mean an individual or Legal Entity exercising permissions granted by this License.

"Source" form shall mean the preferred form for making modifications, including but not limited to software source code, documentation source, and configuration files.

"Object" form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

"Work" shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work (an example is provided in the Appendix below).

"Derivative Works" shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship. For the purposes of this License, Derivative Works shall not include works that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

"Contribution" shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner or by an individual or Legal Entity authorized to submit on behalf of

the copyright owner. For the purposes of this definition, "submitted" means any form of electronic, verbal, or written communication sent to the Licensor or its representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding communication that is conspicuously marked or otherwise designated in writing by the copyright owner as "Not a Contribution."

"Contributor" shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work.

2. Grant of Copyright License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.
3. Grant of Patent License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contributor that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted. If You institute patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Work or a Contribution incorporated within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.
4. Redistribution. You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without modifications, and in Source or Object form, provided that You meet the following conditions:
 - (a) You must give any other recipients of the Work or Derivative Works a copy of this License; and
 - (b) You must cause any modified files to carry prominent notices stating that You changed the files; and
 - (c) You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices from the Source form of the Work, excluding those notices that do not pertain to any part of the Derivative Works; and
 - (d) If the Work includes a "NOTICE" text file as part of its distribution, then any Derivative Works that You distribute must include a readable copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the Derivative Works, in at least one of the following places: within a NOTICE text file distributed as part of the Derivative Works; within the Source form or documentation, if provided along with the Derivative Works; or, within a display generated by the Derivative Works, if and wherever such third-party notices normally appear. The contents

of the NOTICE file are for informational purposes only and do not modify the License. You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum to the NOTICE text from the Work, provided that such additional attribution notices cannot be construed as modifying the License.

You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use, reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

5. Submission of Contributions. Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to the Licensor shall be under the terms and conditions of this License, without any additional terms or conditions. Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.
6. Trademarks. This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the origin of the Work and reproducing the content of the NOTICE file.
7. Disclaimer of Warranty. Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NON-INFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.
8. Limitation of Liability. In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any character arising as a result of this License or out of the use or inability to use the Work (including but not limited to damages for loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.
9. Accepting Warranty or Additional Liability. While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and on Your sole responsibility, not on behalf of any other Contributor, and only if You agree to indemnify, defend, and hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any such warranty or additional liability.

END OF TERMS AND CONDITIONS

25.4.2 LZ4

Lz4 is licensed under the Simplified BSD License reproduced below.

LZ4 Library
Copyright (c) 2011-2020, Yann Collet
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

26 Contact

26.1 Information

All the information on TheGreenBow products is available on our website:

<https://thegreenbow.com/>

26.2 Sales

Phone contact: +33.1.43.12.39.30

E-mail: sales@thegreenbow.com

26.3 Support

There are several pages related to the software's technical support on our website:

Online help

<https://www.thegreenbow.com/en/support/online-support/>

FAQ

<https://www.thegreenbow.com/en/frequently-asked-questions/>

Contact form

Technical support can be reached using the form on our website at the following address:

<https://www.thegreenbow.com/en/support/online-support/technical-support/>



**Protect your connections
in any situation**